


Operating Manual  
**SUNNY BOY STORAGE 2.5**



## Legal Provisions

The information contained in these documents is property of SMA Solar Technology AG. Any publication, whether in whole or in part, requires prior written approval by SMA Solar Technology AG. Internal reproduction used solely for the purpose of product evaluation or other proper use is allowed and does not require prior approval.

### SMA Warranty

You can download the current warranty conditions from the Internet at [www.SMA-Solar.com](http://www.SMA-Solar.com).

### Software licenses

The licenses for the used software modules can be called up on the user interface of the product.

### Trademarks

All trademarks are recognized, even if not explicitly identified as such. Missing designations do not mean that a product or brand is not a registered trademark.

The BLUETOOTH® word mark and logos are registered trademarks of Bluetooth SIG, Inc. and any use of such marks by SMA America LLC and SMA Solar Technology Canada Inc. is under license.

Modbus® is a registered trademark of Schneider Electric and is licensed by the Modbus Organization, Inc.

QR Code is a registered trademark of DENSO WAVE INCORPORATED.

Phillips® and Pozidriv® are registered trademarks of Phillips Screw Company.

Torx® is a registered trademark of Acument Global Technologies, Inc.

### SMA Solar Technology AG

Sonnenallee 1

34266 Niestetal

Germany

Tel. +49 561 9522-0

Fax +49 561 9522-100

[www.SMA.de](http://www.SMA.de)

Email: [info@SMA.de](mailto:info@SMA.de)

Copyright © 2016 SMA Solar Technology AG. All rights reserved.

# Table of Contents

<b>1</b>	<b>Information on this Document .....</b>	<b>6</b>
1.1	Validity .....	6
1.2	Target group.....	6
1.3	Symbols .....	6
1.4	Additional Information .....	7
1.5	Nomenclature.....	7
1.6	Typographies.....	8
<b>2</b>	<b>Safety.....</b>	<b>9</b>
2.1	Intended Use .....	9
2.2	Safety Information .....	9
<b>3</b>	<b>Scope of Delivery.....</b>	<b>11</b>
<b>4</b>	<b>Product Description.....</b>	<b>12</b>
4.1	Sunny Boy Storage .....	12
4.2	Interfaces and Functions .....	15
4.3	LED Signals .....	16
4.4	System Structure .....	17
<b>5</b>	<b>Mounting .....</b>	<b>20</b>
5.1	Requirements for Mounting .....	20
5.2	Mounting the Inverter.....	22
<b>6</b>	<b>Electrical Connection.....</b>	<b>25</b>
6.1	Overview of the Connection Area .....	25
6.2	AC Connection .....	25
6.2.1	Requirements for the AC Connection.....	25
6.2.2	Connecting the Inverter to the Utility Grid .....	27
6.2.3	Connecting Additional Grounding .....	29
6.3	DC Connection .....	30
6.3.1	Assembling the DC Connectors .....	30
6.3.2	Connecting the Power Cable of the Battery .....	32
6.3.3	Disassembling the DC Connectors.....	33
6.4	Connecting the Network and Energy Meter .....	34

6.5	Connecting the Data Cable of the Battery .....	37
<b>7</b>	<b>Commissioning .....</b>	<b>41</b>
7.1	Commissioning Procedure .....	41
7.2	Commissioning the Inverter.....	41
7.3	Configuring the Inverter .....	42
7.4	Starting the Self-Test (For Italy Only) .....	44
<b>8</b>	<b>Using the Inverter User Interface .....</b>	<b>46</b>
8.1	Establishing a connection to the user interface .....	46
8.1.1	Establishing a direct connection via WLAN .....	46
8.1.2	Establishing a Direct Connection via Ethernet.....	47
8.1.3	Establishing a Connection via Ethernet in the local network.....	48
8.2	Logging In and Out of the User Interface.....	49
8.3	Start Page Design of the User Interface.....	51
8.4	Changing the Password.....	54
<b>9</b>	<b>Configuration of the Inverter .....</b>	<b>55</b>
9.1	Changing Operating Parameters.....	55
9.2	Starting the Installation Assistant.....	56
9.3	Configuring the Country Data Set.....	57
9.4	Configuring the Modbus Function .....	57
9.5	Saving the Configuration in a File.....	58
9.6	Adopting a Configuration from a File.....	58
9.7	Activate WPS Function.....	59
9.8	Switching WLAN On and Off.....	59
9.9	Activating the Receipt of Control Signals (Only for Italy).....	60
9.10	Deactivating Grounding Conductor Monitoring.....	60
9.11	Configuring the Energy Meter.....	61
9.12	Configuring Feed-In Management.....	61
<b>10</b>	<b>Disconnecting the Inverter from Voltage Sources.....</b>	<b>63</b>
<b>11</b>	<b>Cleaning the Inverter .....</b>	<b>66</b>
<b>12</b>	<b>Troubleshooting .....</b>	<b>67</b>
12.1	Forgotten Password.....	67

12.2 Event Messages ..... 68

12.3 Updating the Firmware ..... 91

**13 Decommissioning the Inverter ..... 92**

**14 Spare Parts ..... 95**

**15 Technical Data ..... 96**

**16 Contact ..... 100**

**17 EU Declaration of Conformity ..... 102**

# 1 Information on this Document

## 1.1 Validity






This document is valid for the device type "SBS2.5-1VL-10" (Sunny Boy Storage 2.5) from firmware version 02.02.01.R.

## 1.2 Target group

This document is intended for qualified persons and end users. Only qualified persons are allowed to perform the activities marked in this document with a warning symbol and the caption "Qualified person". Tasks that do not require any particular qualification are not marked and can also be performed by end users. Qualified persons must have the following skills:

- Knowledge of how an inverter and lithium-ion batteries work and are operated
- Training in how to deal with the dangers and risks associated with installing and using electrical devices, lithium-ion batteries and systems
- Training in the installation and commissioning of electrical devices and installations
- Knowledge of the applicable standards and directives
- Knowledge of and compliance with this document and all safety information
- Knowledge of and compliance with the documents of the battery manufacturer with all safety information

## 1.3 Symbols

Symbol	Explanation
 <b>DANGER</b>	Indicates a hazardous situation which, if not avoided, will result in death or serious injury
 <b>WARNING</b>	Indicates a hazardous situation which, if not avoided, can result in death or serious injury
 <b>CAUTION</b>	Indicates a hazardous situation which, if not avoided, can result in minor or moderate injury
<b>NOTICE</b>	Indicates a situation which, if not avoided, can result in property damage
 <b>QUALIFIED PERSON</b>	Sections describing activities to be performed by qualified persons only
	Information that is important for a specific topic or goal, but is not safety-relevant
<input type="checkbox"/>	Indicates a requirement for meeting a specific goal
<input checked="" type="checkbox"/>	Desired result
<b>×</b>	A problem that might occur

## 1.4 Additional Information

Links to additional information can be found at [www.SMA-Solar.com](http://www.SMA-Solar.com):

Document title	Document type
"Efficiency and Derating" Efficiency and Derating Behavior of the Sunny Boy, Sunny Tripower and Sunny Mini Central Inverters	Technical Information
"Criteria for Selecting a Residual-Current Device" Criteria for Selecting a Residual-Current Device	Technical Information
"Circuit Breaker" Dimensioning and Selection of a Suitable AC Circuit Breaker for Inverters under PV-Specific Influences	Technical Information
"Application for SMA Grid Guard Code"	Form
"Webconnect Systems in Sunny Portal" Registration in Sunny Portal	User Manual
"SMA Modbus® Interface" Information on the commissioning and configuration of the SMA Modbus interface	Technical Information
"SunSpec® Modbus® Interface" Information on the commissioning and configuration of the SunSpec Modbus interface	Technical Information
"SMA Modbus® Interface" List with the product specific SMA Modbus registers	Technical Information
"SunSpec® Modbus® Interface" List with the product specific SunSpec Modbus registers	Technical Information
"Parameters and Measured Values" Overview of All Inverter Operating Parameters and Their Configuration Options	Technical Information

## 1.5 Nomenclature

Complete designation	Designation in this document
Sunny Boy Storage	Inverter, product

## 1.6 Typographies

Typography	Use	Example
<b>bold</b>	<ul style="list-style-type: none"><li>• Terminals</li><li>• Slots</li><li>• Parameters</li><li>• Elements on the user interface</li><li>• Elements to be selected</li><li>• Elements to be entered</li></ul>	<ul style="list-style-type: none"><li>• The value can be found in the field <b>Energy</b>.</li><li>• Select <b>Settings</b>.</li><li>• Enter <b>10</b> in the field <b>Minutes</b>.</li></ul>
<b>&gt;</b>	<ul style="list-style-type: none"><li>• Connects several elements to be selected</li></ul>	<ul style="list-style-type: none"><li>• Select <b>Settings &gt; Date</b>.</li></ul>
<b>[Button]</b>	<ul style="list-style-type: none"><li>• Button to be selected or pressed</li></ul>	<ul style="list-style-type: none"><li>• Select <b>[Next]</b>.</li></ul>



## 2 Safety

### 2.1 Intended Use

The Sunny Boy Storage is a single-phase, AC coupled battery inverter for parallel grid operation. The Sunny Boy Storage converts the direct current supplied by a battery into grid-compliant alternating current. With a lithium-ion battery and the energy meter, the Sunny Boy Storage becomes a system for increased self-consumption.

The Sunny Boy Storage must only be operated in connection with an intrinsically safe lithium-ion battery approved by SMA Solar Technology AG. An updated list of batteries approved by SMA Solar Technology AG is available at [www.SMA-Solar.com](http://www.SMA-Solar.com).

The lithium-ion battery must comply with the locally applicable standards and directives and must be intrinsically safe (see technical information "SMA Flexible Storage System - Detailed explanations of the safety concept" for detailed explanations regarding the safety concept of battery inverters by SMA Solar Technology AG). The battery management of the used lithium-ion battery must be compatible with the Sunny Boy Storage. The entire battery voltage range must be completely within the permissible input voltage range of the Sunny Boy Storage. The maximum permissible DC input voltage of the Sunny Boy Storage must not be exceeded.

The Sunny Boy Storage is suitable for indoor and outdoor use.

The Sunny Boy Storage is not suitable for supplying life-sustaining medical devices. A power outage must not lead to personal injury.

All components must remain within their permitted operating ranges and their installation requirements at all times.

The product must only be used in countries for which it is approved or released by SMA Solar Technology AG and the grid operator.

Use this product only in accordance with the information provided in the enclosed documentation and with the locally applicable standards and directives. Any other application may cause personal injury or property damage.

Alterations to the product, e.g. changes or modifications, are only permitted with the express written permission of SMA Solar Technology AG. Unauthorized alterations will void guarantee and warranty claims and in most cases terminate the operating license. SMA Solar Technology AG shall not be held liable for any damage caused by such changes.

Any use of the product other than that described in the Intended Use section does not qualify as appropriate.

The enclosed documentation is an integral part of this product. Keep the documentation in a convenient place for future reference and observe all instructions contained therein.

The type label must remain permanently attached to the product.

### 2.2 Safety Information

This section contains safety information that must be observed at all times when working on or with the product.

To prevent personal injury and property damage and to ensure long-term operation of the product, read this section carefully and observe all safety information at all times.

**⚠ DANGER****Danger to life from electric shock due to live DC cables at the battery.**

The DC cables connected to a battery are live. Touching the DC conductors or the live components leads to lethal electric shocks.

- Do not touch non-insulated cable ends.
- Do not touch the DC conductors.
- Do not touch any live components.
- Have the inverter and the battery mounted, installed and commissioned only by qualified persons with the appropriate skills.
- Observe all safety information of the battery manufacturer.
- Prior to performing any work on the inverter or the battery, disconnect the inverter from all voltage sources as described in this document.
- If an error occurs, have it rectified by qualified persons only.

**⚠ WARNING****Risk of injury due to short-circuit currents**

Short-circuit currents in the battery can cause heat build-up and electric arcs. Burns or eye injuries due to flashes may result.

- Remove watches, rings and other metal objects.
- Use insulated tools.
- Do not place tools or metal parts on the battery.

**⚠ CAUTION****Risk of burns due to hot enclosure parts**

Some parts of the enclosure can get hot during operation.

- Mount the inverter in such a way that it cannot be touched inadvertently during operation.

**NOTICE****Damage to the inverter due to the use of cleaning agents**

- If the inverter is dirty, clean the enclosure, the enclosure lid, the type label and the LEDs using only clean water and a cloth.

### 3 Scope of Delivery

Check the scope of delivery for completeness and any externally visible damage. Contact your distributor if the scope of delivery is incomplete or damaged.




Figure 1: Components included in the scope of delivery

Position	Quantity	Designation
A	1	Inverter
B	1	Connection cap
C	1	Clamping bracket
D	1	Cylindrical screw M5 x 16
E	1	Spring lock washer
F	1	Washer
G	1	Connecting terminal plate for the AC connection
H	1	Plug for the battery communication connection
I	1	Positive DC connector
K	1	Negative DC connector
L	2	Sealing plug
M	1	<p>Quick reference guide with password label on the rear side</p> <p>The label contains the following information:</p> <ul style="list-style-type: none"> <li>PIC (Product Identification Code) identification key for registering the system in Sunny Portal</li> <li>RID (Registration Identifier) registration ID for registering the system in Sunny Portal</li> <li>WLAN password WPA2-PSK (WiFi Protected Access 2 - Preshared Key) for direct connection to the inverter via WLAN</li> </ul>

## 4 Product Description

### 4.1 Sunny Boy Storage

The Sunny Boy Storage is a single-phase, AC coupled battery inverter for parallel grid operation. The Sunny Boy Storage converts the direct current supplied by a battery into grid-compliant alternating current. With a lithium-ion battery and the energy meter, the Sunny Boy Storage becomes a system for increased self-consumption.




















Figure 2: Design of the Sunny Boy Storage

Position	Designation
A	Connection cap
	Connection area with cable glands for connection to the utility grid, the battery communication cable and a network cable

Position	Designation
B	<p>LEDs</p> <p>The LEDs indicate the operating state of the inverter.</p>
C	<p>Type label</p> <p>The type label uniquely identifies the inverter. You will require the information on the type label to use the product safely and when seeking customer support from the SMA Service Line. The type label must remain permanently attached to the product. You will find the following information on the type label:</p> <ul style="list-style-type: none"> <li>• Device type (Model)</li> <li>• Serial number (Serial No.)</li> <li>• Date of manufacture</li> <li>• Identification key (PIC) for registration in Sunny Portal</li> <li>• Registration ID (RID) for registration in Sunny Portal</li> <li>• WLAN password (WPA2-PSK) for direct access to the inverter via WLAN</li> <li>• Device-specific characteristics</li> </ul>

## Symbols on the Inverter and on the Type Label

Symbol	Explanation
	<p>Inverter</p> <p>Together with the green LED, this symbol indicates the operating state of the inverter.</p>
	<p>Observe the documentation</p> <p>Together with the red LED, this symbol indicates an error.</p>
	<p>Data transmission</p> <p>Together with the blue LED, this symbol indicates the status of the network connection.</p>
	<p>Grounding conductor</p> <p>This symbol indicates the position for connecting a grounding conductor.</p>
	<p>Danger to life due to high voltages in the inverter; observe a waiting time of five minutes</p> <p>High voltages that can cause lethal electric shocks are present in the live components of the inverter. Prior to performing any work on the inverter, disconnect it from all voltage sources as described in this document .</p>

Symbol	Explanation
	<p>Risk of burns due to hot surfaces</p> <p>The product can get hot during operation. Avoid contact during operation. Prior to performing any work on the product, allow the product to cool down sufficiently.</p>
	<p>Danger to life due to electric shock</p> <p>The product operates at high voltages. Prior to performing any work on the product, disconnect the product from voltage sources. All work on the product must be carried out by electrically qualified persons only.</p>
	<p>Observe the documentation</p> <p>Observe all documentation supplied with the product.</p>
	<p>Danger</p> <p>This symbol indicates that the inverter must be additionally grounded if additional grounding or equipotential bonding is required at the installation site (see Section 6.2.3 "Connecting Additional Grounding", page 29).</p>
	Direct current
	The product does not have a transformer.
	Alternating current
	<p>WEEE designation</p> <p>Do not dispose of the product together with the household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site.</p>
	<p>CE marking</p> <p>The product complies with the requirements of the applicable EU directives.</p>
	<p>Degree of protection IP65</p> <p>The product is protected against dust intrusion and water jets from any angle.</p>
	The product is suitable for outdoor installation.

## 4.2 Interfaces and Functions

The inverter is equipped with the following interfaces and functions:

### User interface for the monitoring and configuration of the inverter

The inverter is standard-equipped with an integrated web server, which provides a user interface for configuring and monitoring the inverter. The inverter user interface can be called up via the web browser if there is an existing WLAN or Ethernet connection to a computer, tablet PC or smartphone.

### SMA Speedwire

The inverter is equipped with SMA Speedwire as standard. SMA Speedwire is a type of communication based on the Ethernet standard. This enables inverter-optimized 10 or 100 Mbit data transmission between Speedwire devices in PV systems and the user interface of the inverter.

### SMA Webconnect

The inverter is equipped with a Webconnect function as standard. The Webconnect function enables direct data transmission between the inverters of a small-scale system and the Internet portal Sunny Portal without any additional communication device and for a maximum of 4 inverters per Sunny Portal system. In large-scale PV power plants with more than 4 inverters, there is the option of establishing data transmission between the inverters and the Sunny Portal web-based monitoring platform via the Sunny Home Manager or to distribute the inverters over several plants in the Sunny Portal. If there is an existing WLAN or Ethernet connection, you can directly access your Sunny Portal system via the web browser on the computer, tablet PC or smartphone.

### WLAN

The inverter is equipped with a WLAN interface as standard. The inverter is delivered with the WLAN interface activated as standard. If you do not want to use WLAN, you can deactivate the WLAN interface.

In addition, the inverter has a WPS (WiFi Protected Setup) function. The WPS function is for automatically connecting the inverter to a device in the same network as the inverter (e.g. router, computer, tablet PC or smartphone).

#### Limited function in the event of frost

The integrated WLAN interface is only designed for temperatures down to -20°C.

- Deactivate the WLAN interface at low temperatures (see Section 9.8 "Switching WLAN On and Off", page 59).

### Modbus

The inverter is equipped with a Modbus interface. The Modbus interface is deactivated by default and must be configured as needed.

The Modbus interface of the supported SMA devices is designed for industrial use and has the following tasks:

- Remote query of measured values
- Remote setting of operating parameters
- Setpoint specifications for system control

## Grid Management Services

The inverter is equipped with service functions for grid management.

Depending on the requirements of the grid operator, you can activate and configure the functions (e.g. active power limitation) via operating parameters.

### All-pole sensitive residual-current monitoring unit

The all-pole sensitive residual-current monitoring unit detects alternating and direct differential currents. In single-phase and three-phase inverters, the integrated differential current sensor detects the current difference between the neutral conductor and the line conductor(s). If the current difference increases suddenly, the inverter disconnects from the utility grid.

## 4.3 LED Signals

The LEDs indicate the operating state of the inverter.

LED	Status	Explanation
Green LED	flashing: 2 s on 2 s off	Waiting for connection conditions The conditions for feed-in operation are not yet met. As soon as the conditions are met, the inverter will start feed-in operation.
	flashing quickly	Update of central processing unit The central processing unit of the inverter is being updated.
	glowing	Parallel grid operation
Red LED	glowing	Event occurred If an event occurs, a distinct event message and the corresponding event number will be displayed in addition on the inverter user interface or in the communication product.
Blue LED	flashes slowly for approx. one minute	Communication connection is being established The inverter is establishing a connection to a local network or is establishing a direct connection to an end device via Ethernet (e.g. computer, tablet PC or smartphone).
	flashes quickly for approx. two minutes	WPS active The WPS function is active.
	glowing	Communication active There is an active connection with a local network or there is a direct connection with an end device via Ethernet (e.g. computer, tablet PC or smartphone).



## 4.4 System Structure

### SMA Flexible Storage System without Sunny Home Manager




Figure 3: Overview of a system with Sunny Boy Storage and Energy Meter (example)

Position	Designation
A	PV array
B	PV inverter with SMA Speedwire/Webconnect (single-phase)
C	PV inverter with SMA Speedwire/Webconnect (three-phase)
D	Loads
E	Battery
F	Sunny Boy Storage
G	Sunny Portal
H	Internet
I	Router/network switch
K	Utility grid
L	Feed-in and purchased electricity meter
M	Energy Meter
a	DC

Position	Designation
b	AC
c	Speedwire
d	Internet connection

## SMA Flexible Storage System with Sunny Home Manager




Figure 4: Overview of a SMA Flexible Storage System with Sunny Boy Storage (example)

Position	Designation
A	PV array
B	PV Inverters with BLUETOOTH (single-phase or three-phase)
C	PV inverter with SMA Speedwire/Webconnect (single-phase or three-phase)
D	Controlled load
E	Radio-controlled socket
F	Non-controllable load
G	Battery
H	Sunny Boy Storage
I	Sunny Home Manager
K	Sunny Portal

Position	Designation
L	Internet
M	Router/network switch
N	Utility grid
O	Feed-in and purchased electricity meter
P	SMA Energy Meter
a	DC
b	AC
c	Speedwire
d	Internet connection

## 5 Mounting

### 5.1 Requirements for Mounting

#### Requirements for the mounting location:

##### **⚠ WARNING**

##### **Danger to life due to fire or explosion**

Despite careful construction, electrical devices can cause fires.

- Do not mount the inverter in areas containing highly flammable materials or gases.
- Do not mount the inverter in a potentially explosive atmosphere.

- ☐ Do not mount the inverter on a pillar.
- ☐ The mounting location must be suitable for the weight and dimensions of the inverter (see Section 15 "Technical Data", page 96).
- ☐ The mounting location must not be exposed to direct solar irradiation. Direct solar irradiation can result in the premature aging of the exterior plastic parts of the inverter and direct solar irradiation can cause the inverter to overheat. When becoming too hot, the inverter reduces its power output to avoid overheating.
- ☐ The mounting location should be freely and safely accessible at all times without the need for any auxiliary equipment (such as scaffolding or lifting platforms). Non-fulfillment of these criteria may restrict servicing.
- ☐ To ensure optimum operation, the ambient temperature should be between  $-25^{\circ}\text{C}$  and  $+40^{\circ}\text{C}$ .
- ☐ Climatic conditions must be met (see Section 15 "Technical Data", page 96).

#### Permitted and prohibited mounting positions:

- ☐ The inverter must only be mounted in one of the permitted positions. This will ensure that no moisture can penetrate the inverter.
- ☐ The inverter should be mounted in such a way that LED signals can be read without difficulty.




Figure 5: Permitted and prohibited mounting positions:


**Dimensions for mounting:**

Figure 6: Position of the anchoring points

**Recommended clearances:**

If you maintain the recommended clearances, adequate heat dissipation will be ensured. Thus, you will prevent power reduction due to excessive temperature.

- ☐ Maintain the recommended clearances to walls as well as to other inverters or objects.
- ☐ If multiple inverters are mounted in areas with high ambient temperatures, increase the clearances between the inverters and ensure sufficient fresh-air supply.




Figure 7: Recommended clearances

## 5.2 Mounting the Inverter

### ⚠ QUALIFIED PERSON

#### Additionally required mounting material (not included in the scope of delivery):

- ☐ Two stainless steel hexagon head wood screws (AF 10, diameter 6 mm), screw length must be suitable for the support surface and the weight of the inverter (fastening bracket thickness: 4 mm)
- ☐ If necessary, two screw anchors suitable for the support surface and the screws

### ⚠ CAUTION

#### Risk of injury when lifting the inverter, or if it is dropped

The inverter weighs 9 kg. There is risk of injury if the inverter is lifted incorrectly or dropped while being transported or when attaching it to or removing it from the wall mounting bracket.

- Transport and lift the inverter carefully.

#### Procedure:

##### 1. ⚠ CAUTION


#### Risk of injury due to damaged cables

There may be power cables or other supply lines (e.g. gas or water) routed in the wall.


- Ensure that no lines are laid in the wall which could be damaged when drilling holes.

2. Mark the position of the drill holes. Align the markings horizontally.
3. Drill the holes.

4. Insert screw anchors into the drill holes if the support surface requires them.
5. When screwing the screws in, make sure that there is at least 6 mm left between the screw head and the support surface.
6. Hang the inverter onto the screws using the metal brackets.



7. Tighten the screws hand-tight using a ratchet or box wrench. When doing this you can compensate for any misalignment of the drill holes by aligning the metal brackets accordingly.




8. Ensure that the inverter is securely in place.

9. **NOTICE****Damage to the inverter due to moisture ingress**


If the electrical connection is not made immediately after the installation, the inverter is not sealed and moisture can penetrate the inverter. The inverter is only sealed if the DC connectors are connected to the inverter with the DC conductors or with sealing plugs.

If the electrical connection is to be carried out at a later time, close the DC inputs on the inverter with DC connectors and sealing plugs as described below.

- Do not insert the sealing plugs directly into the DC inputs on the inverter.
- For unused DC connectors, push down the clamping bracket and push the swivel nut up to the thread.
- Insert the sealing plug into the DC connector.



- Insert the DC connectors with sealing plugs into the corresponding DC inputs on the inverter.



- ☑ The DC connectors snap into place.
- Ensure that the DC connectors with sealing plugs are securely in place.



## 6 Electrical Connection

### 6.1 Overview of the Connection Area




Figure 8: Connection areas at the bottom of the inverter and cable glands at the connection cap

Position	Designation
A	DC connectors for connecting the battery power cable
B	Pin connector for connecting the network cable
C	Pin connector for connecting the data cable of the battery.
D	Jack for the AC connection
E	Connection point for an additional grounding
F	Cable gland for the AC connection
G	Cable gland with cable support sleeve for connecting the network cable and the battery communication cable

### 6.2 AC Connection

#### 6.2.1 Requirements for the AC Connection

**Cable requirements:**

- ☐ External diameter: 5 mm to 13 mm
- ☐ Conductor cross-section: 1.5 mm<sup>2</sup> to 4 mm<sup>2</sup>
- ☐ Insulation stripping length: 15 mm

- ☐ Sheath stripping length: 70 mm
- ☐ The cable must be dimensioned in accordance with the local and national directives for the dimensioning of cables. The requirements for the minimum wire size derive from these directives. Examples of factors influencing cable dimensioning are: nominal AC current, type of cable, routing method, cable bundling, ambient temperature and maximum desired line losses (for calculation of line losses, see the design software "Sunny Design" from software version 2.0 at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

#### Load-break switch and cable protection:

##### **NOTICE**

#### **Damage to the inverter due to the use of screw-type fuses as load-break switches**

Screw-type fuses (e.g. DIAZED fuse or NEOZED fuse) are not load-break switches.

- Do not use screw-type fuses as load-break switches.
  - Use a load-break switch or circuit breaker as a load disconnection unit (for information and design examples, see the Technical Information "Circuit Breaker" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).
- ☐ In PV systems with multiple inverters, protect each inverter with a separate circuit breaker. Make sure to observe the maximum permissible fuse protection (see Section 1.5 "Technical Data", page 96). This will prevent residual voltage being present at the corresponding cable after disconnection.
  - ☐ Loads installed between the inverter and the circuit breaker must be fused separately.

#### Residual-current monitoring unit:

- ☐ If an external residual-current device is required, install a residual-current device which trips at a residual current of 100 mA or higher (for details on selecting a residual-current device, see the Technical Information "Criteria for Selecting a Residual-Current Device" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

#### Overvoltage category:

The inverter can be used in grids of overvoltage category III or lower in accordance with IEC 60664-1. That means that the inverter can be permanently connected to the grid-connection point of a building. In case of installations with long outdoor cabling routes, additional measures to reduce overvoltage category IV to overvoltage category III are required (see the Technical Information "Overvoltage Protection" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

#### Grounding conductor monitoring:

The inverter is equipped with a grounding conductor monitoring device. This grounding conductor monitoring device detects when there is no grounding conductor connected and disconnects the inverter from the utility grid if this is the case. Depending on the installation site and grid configuration, it may be advisable to deactivate the grounding conductor monitoring. This is necessary, for example, in an IT system if there is no neutral conductor present and you intend to install the inverter between two line conductors. If you are uncertain about this, contact your grid operator or SMA Solar Technology AG.

- Grounding conductor monitoring must be deactivated after initial start-up depending on the grid configuration (see Section 9.10, page 60).

### **i Safety in accordance with IEC 62109 when the grounding conductor monitoring is deactivated**

In order to guarantee safety in accordance with IEC 62109 when the grounding conductor monitoring is deactivated, you have to connect additional grounding:

- In order to guarantee safety in accordance with IEC 62109 when the grounding conductor monitoring is deactivated, you have to connect additional grounding (see Section 6.2.3, page 29): The additional grounding conductor must have the same cross-section as the connected grounding conductor at the connecting terminal plate for the AC cable. This prevents touch current if the grounding conductor at the connecting terminal plate for the AC cable fails.

### **i Connection of additional grounding**

In some countries, additional grounding is generally required. In each case, observe the locally applicable regulations.

- If additional grounding is required, connect an additional grounding that has at least the same cross-section as the connected grounding conductor to the connecting terminal plate for the AC cable (see Section 6.2.3, page 29). This prevents touch current if the grounding conductor at the connecting terminal plate for the AC cable fails.

## **6.2.2 Connecting the Inverter to the Utility Grid**


### **⚠ QUALIFIED PERSON**

#### **Requirements:**


- ☐ Only the connecting terminal plate supplied may be used for the AC connection.
- ☐ The connection requirements of the grid operator must be met.
- ☐ The grid voltage must be in the permissible range. The exact operating range of the inverter is specified in the operating parameters.

#### **Procedure:**

1. Disconnect the AC circuit breaker and secure it against reconnection.
2. Unscrew the swivel nut from the cable gland for the AC connection at the connector cap.





3. Thread the swivel nut over the AC cable.



## 4. Thread the AC cable through the cable gland of the AC connection:

- If the external diameter of the cable is 5 mm to 7 mm, thread the AC cable through the cable gland directly.
- If the external diameter of the AC cable is 8 mm to 13 mm, first remove the inner sealing ring from the cable gland and then thread the AC cable through the cable gland. When doing so, ensure that the outer sealing ring is positioned correctly in the cable gland.




## 5. Dismantle 70 mm of the AC cable.

## 6. Shorten L and N by 5 mm each. Thus, the grounding conductor will be released from the connecting terminal plate last when tensile load is applied.

## 7. Strip 15 mm of the insulation of L, N and the grounding conductor.

## 8. Connect L, N and the grounding conductor to the connecting terminal plate for the AC connection in accordance with the labeling. When doing so, ensure that the conductors are plugged completely into the terminals up to the insulation.


Useful hint: To release the conductors from the terminals, the terminals must be opened. To do this, stick a flat-blade screwdriver (blade width: 3 mm) as far as it can go into the rectangular opening behind the terminal.



## 9. Ensure that all terminals are allocated to the correct conductors.

## 10. Make sure that all conductors are securely in place.

11. Plug the connecting terminal plate with the connected conductors for the AC connection into the slot in the inverter until the connecting terminal plate clicks into place.



12. Ensure that the connecting terminal plate is securely in place by slightly pulling it.

### 6.2.3 Connecting Additional Grounding

#### **⚠ QUALIFIED PERSON**

If additional grounding or equipotential bonding is required locally, you can connect additional grounding to the inverter. This prevents touch current if the grounding conductor at the terminal for the AC cable fails.

The required clamping bracket, the cylindrical screw M5x16, the washer and the spring lock washer are part of the scope of delivery of the inverter.

#### **i Grounding of the battery**

The battery must not be grounded via the inverter.

- Do not connect the grounding of the battery to the connection point for additional grounding on the inverter.
- Ground the battery according to the battery manufacturer's specifications.

#### **Cable requirements:**

#### **i Use of fine-stranded conductors**

You can use an inflexible or a flexible, fine-stranded conductor.


- When using a fine-stranded conductor, it has to be double crimped by a ring terminal lug. Make sure that no insulated conductor is visible when pulling or bending. This will ensure sufficient strain relief by means of the ring terminal lug.

☐ Grounding cable cross-section: max. 10 mm<sup>2</sup>

#### **Procedure:**

1. Strip off 12 mm of the grounding cable insulation.
2. Insert the screw through the spring lock washer, the clamping bracket and the washer.
3. Lightly screw the screw into the thread of the connection point for the additional grounding.

4. Lead the grounding cable between the washer and clamping bracket and tighten the screw (torque: 6 Nm) using a Torx screwdriver (TX 25).



## 6.3 DC Connection

### 6.3.1 Assembling the DC Connectors

#### **⚠ QUALIFIED PERSON**

The battery connection cables must be fitted with the supplied DC connectors. Assemble the DC connectors as described in the following. Be sure to observe the correct polarity. The DC connectors are marked with the symbols "Battery (+)" and "Battery (-)".




Figure 9: Negative (A) and positive (B) DC connectors

#### **Cable requirements:**

- ☐ Cable type: PV1-F, UL-ZKLA, USE2
- ☐ External diameter: 5 mm to 8 mm
- ☐ Conductor cross-section: 2.5 mm<sup>2</sup> to 6 mm<sup>2</sup>
- ☐ Qty single wires: minimum 7
- ☐ Nominal voltage: minimum 1000 V

#### **⚠ DANGER**


#### **Danger to life from electric shock due to live DC cables at the battery.**

The DC cables connected to a battery are live. Touching the DC conductors or the live components leads to lethal electric shocks.


- Ensure that the inverter is disconnected from all voltage sources.
- Do not touch non-insulated cable ends.
- Do not touch the DC conductors.

**Procedure:**


1. Strip 12 mm of the cable insulation.
2. Insert the stripped cable into the DC connector up to the stop. When doing so, ensure that the stripped cable and the DC connector are of the same polarity.



3. Press the clamping bracket down until it audibly snaps into place.




- ✓ The stranded wire can be seen inside the clamping bracket chamber.



- ✗ The stranded wire cannot be seen in the chamber?


The cable is not correctly in place.

- Release the clamping bracket. To do so, insert a screwdriver (blade width: 3.5 mm) into the clamping bracket and pry the clamping bracket open.



- Remove the cable and go back to step 2.

4. Push the swivel nut up to the thread and tighten (torque: 2 Nm).



### 6.3.2 Connecting the Power Cable of the Battery

#### ⚠ QUALIFIED PERSON

##### NOTICE

#### Damage to the DC connectors due the use of contact cleaner or other cleaning agents

Some contact cleaners or other cleaning agents may contain substances that decompose the plastic of the DC connectors.

- Do not use contact cleaners or other cleaning agents for cleaning the DC connectors.

#### ⚠ DANGER

#### Danger to life from electric shock due to live DC cables when connecting an PV array

If the DC connectors with the DC cables of the PV array were accidentally connected to the inverter, the high voltages of the PV array are present at the DC conductors. Touching the DC conductors or the live components leads to lethal electric shocks.

- It is imperative that the DC connectors are not disassembled during the day.
- Stop working on the inverter and wait until dark.
- If you would like to leave the PV system to continue work when it is dark, set up protection against contact (e.g. a fence).
- Disassemble and then assemble the DC connectors again only once it is dark.

#### Requirements:


- ☐ Only the supplied connectors for connecting the battery power cable may be used.
- ☐ The length of the battery power cable must not exceed 10 m.

#### Procedure:

1. Ensure that the DC connectors have the correct polarity.

If the DC connector is equipped with a DC cable of the wrong polarity, the DC connector must be reassembled. The DC cable must always have the same polarity as the DC connector.

2. Connect the assembled DC connectors to the inverter.



- ☒ The DC connectors snap into place.

3. Ensure that all DC connectors are securely in place.



### 6.3.3 Disassembling the DC Connectors

#### **⚠ QUALIFIED PERSON**

To disassemble the DC connectors (e.g. due to faulty assembly), proceed as follows.

#### **⚠ DANGER**

##### **Danger to life from electric shock due to live DC cables at the battery.**

The DC cables connected to a battery are live. Touching the DC conductors or the live components leads to lethal electric shocks.

- Ensure that the inverter is disconnected from all voltage sources.
- Do not touch non-insulated cable ends.
- Do not touch the DC conductors.

#### **⚠ DANGER**


##### **Danger to life from electric shock due to live DC cables when connecting an PV array**

If the DC connectors with the DC cables of the PV array were accidentally connected to the inverter, the high voltages of the PV array are present at the DC conductors. Touching the DC conductors or the live components leads to lethal electric shocks.


- It is imperative that the DC connectors are not disassembled during the day.
- Stop working on the inverter and wait until dark.
- If you would like to leave the PV system to continue work when it is dark, set up protection against contact (e.g. a fence).
- Disassemble and then assemble the DC connectors again only once it is dark.

#### **Procedure:**


1. Release and remove all DC connectors. To do this, insert a flat-blade screwdriver or an angled screwdriver (blade width 3.5 mm) into one of the slide slots and pull the DC connectors out in a downward direction. Do not pull on the cable.




2. Remove the DC connector swivel nut.



3. Unlock the DC connector. To do this, insert a flat-blade screwdriver (blade width: 3.5 mm) into the side catch mechanism and pry the catch mechanism open.



4. Carefully pull the DC connector apart.
5. Release the clamping bracket. To do so, insert a flat-blade screwdriver (blade width: 3.5 mm) into the clamping bracket and pry the clamping bracket open.



6. Remove the cable.

## 6.4 Connecting the Network and Energy Meter

### **⚠ QUALIFIED PERSON**

#### **⚠ DANGER**

##### **Danger to life due to electric shock**

Overvoltages (e. g. in the case of a flash of lightning) can be further conducted into the building and to other connected devices in the same network via network cables or other data cables if there is no overvoltage protection.

- Ensure that all devices in the same network and the battery are integrated in the existing overvoltage protection.
- When laying the network cables or other data cables outdoors, attention must be given to suitable overvoltage protection at the cable transition from the inverter or the battery outdoors to the inside of a building.

##### **i Failure-free operation of all system components due to tethered connection**

- To ensure failure-free operation, SMA Solar Technology AG recommends connecting all system components with each other via Speedwire.

### Connection variant: Flexible Storage System without Sunny Home Manager




Figure 10: Network connection in the SMA Flexible Storage System without Sunny Home Manager (example)

### Connection variant: Flexible Storage System with Sunny Home Manager




Figure 11: Network connection in the SMA Flexible Storage System With Sunny Home Manager (example)

#### Additionally required material (not included in the scope of delivery):

- ☐ One network cable for the direct connection with the Energy Meter or for the connection with the local network (e.g. via a router)
- ☐ Where required: Field-assembly RJ45 connector for the network cable. SMA Solar Technology AG recommends the connector "MFP8 T568 A Cat.6A" from "Telegärtner".

#### Cable requirements:


The cable length and quality affect the quality of the signal. Observe the following cable requirements.

- ☐ Cable type: 100BaseTx
- ☐ Cable category: Cat5, Cat5e, Cat6, Cat6a or Cat7
- ☐ Plug type: RJ45 of Cat5, Cat5e, Cat6 or Cat6a
- ☐ Shielding: SF/UTP, S/UTP, SF/FTP or S/FTP
- ☐ Number of insulated conductor pairs and insulated conductor cross-section: at least  $2 \times 2 \times 0.22 \text{ mm}^2$
- ☐ Maximum cable length between two nodes when using patch cables: 50 m


- ☐ Maximum cable length between two nodes with installation cable: 100 m
- ☐ UV-resistant for outdoor use

**Procedure:**

1. When using a self-assembly network cable, assemble the RJ45 connector and connect to the network cable (see connector documentation).
2. Unscrew the swivel nut from the cable gland for the connection of a network cable and the battery communication cable at the connection cap.
3. Thread the swivel nut over the network cable.
4. Press the cable support sleeve out of the cable gland.
5. Remove the filler plug from the cable support sleeve.
6. Route the network cable through an opening in the cable support sleeve.



7. Thread the network cable through the cable gland.
8. Insert the RJ45 plug of the network cable into the network pin connector on the inverter until it snaps into place.



9. Ensure that the network connector is securely in place by pulling slightly on the network cable.
10. Connect the other end of the network cable to the local network (e.g. via a router). You can only connect the inverter to other nodes via star topology.
11. Connecting the data cable of the battery (see Section 6.5, page 37).

## 6.5 Connecting the Data Cable of the Battery

### QUALIFIED PERSON

#### DANGER

##### **Danger to life due to electric shock**

Overvoltages (e. g. in the case of a flash of lightning) can be further conducted into the building and to other connected devices in the same network via network cables or other data cables if there is no overvoltage protection.

- Ensure that all devices in the same network and the battery are integrated in the existing overvoltage protection.
- When laying the network cables or other data cables outdoors, attention must be given to suitable overvoltage protection at the cable transition from the inverter or the battery outdoors to the inside of a building.

#### **Failure-free operation of all system components due to tethered connection**

- To ensure failure-free operation, SMA Solar Technology AG recommends connecting all system components with each other via Speedwire.

#### **Communication between Inverter and Battery**

- Communication between the inverter and the battery takes place via the battery communication cable via CAN bus.


#### **Additionally required material (not included in the scope of delivery):**

- ☐ One battery communication cable for the communication between inverter and battery

#### **Cable requirements:**


- ☐ Cable type: Twisted Pair
- ☐ Shielding: yes
- ☐ Conductor cross-section: 0.25 mm<sup>2</sup> to 0.34 mm<sup>2</sup>
- ☐ Number of conductor pairs: 4
- ☐ Maximum cable length: 10 m
- ☐ UV-resistant for outdoor use. SMA Solar Technology AG recommends the cable "UC900 SS23 Cat.7 PE"

Plug assignment:


Plug	Position	Assignment
	A	Not assigned
	B	Enable
	C	GND and shielding
	D	CAN L
	E	CAN H
	F	+12V

Procedure:

- 1. Thread the swivel nut over the data cable of the battery.
- 2. Route the data cable of the battery through an opening in the cable support sleeve.




- 3. Insert the data cable of the battery through the cable gland.
- 4. Dismantle the data cable of the battery.
- 5. Cut off an entire pair of conductors and an insulated conductor. Make sure that **CAN L** and **CAN H** as well as **+12V** and **GND** each consist of a pair of conductors.




Conductor	Assignment
A	Not assigned
B	Enable
C	GND and shielding
D	CAN L
E	CAN H
F	+12V

- 6. Strip the insulation off the wires.


7. Combine the shielding and insert it into a bootlace ferrule (1.5 mm<sup>2</sup> without collar) together with **GND** and crimp using a crimping tool.




8. Connect the shielding and **GND** with the bootlace ferrule to the **GND** terminal of the plug for the battery communication connection. Observe the plug assignment.




9. Connect the remaining conductors of the battery communication cable to the plug for the battery communication connection. Pay attention to the plug assignment and make sure that **CAN L** and **CAN H** as well as **+12V** and **GND** each consist of a pair of conductors.




10. Make sure that the conductors are plugged into the plug tightly by pulling slightly on the conductors.
11. Insert the plug for the battery communication connection into the pin connector on the right of the network jack. The terminals must face forward and the terminals for releasing the conductors must face to the rear towards the mounting surface.




12. Make sure that the plug for the battery communication cable is plugged in tightly.
13. Push the seal insert back into the cable gland.



14. Screw the swivel nut hand-tight onto the cable gland for the connection of the network cable and the battery communication cable.
15. Tighten the connection cap to the inverter using the three screws and a Torx screwdriver (TX20) (torque: 3.5 Nm).



16. Screw the swivel nuts onto the cable glands on the connection cap.



17. Connect the other end of the battery communication cable directly to the battery (see the battery manufacturer's manual).



## 7 Commissioning

### 7.1 Commissioning Procedure

#### QUALIFIED PERSON

This section describes the commissioning procedure and gives an overview of the steps you must perform in the prescribed order.

Procedure	See
1. Commission the inverter.	Section 7.2, page 41
2. Establish a connection to the user interface of the inverter. There are three connection options available to choose from: <ul style="list-style-type: none"> <li>• Direct connection via WLAN</li> <li>• Direct connection via Ethernet</li> <li>• Connection via Ethernet in the local network</li> </ul>	Section 8.1, page 46
3. Log into the user interface.	Section 8.2, page 49
4. Configure the inverter. Please note, that the personal SMA Grid Guard code for changing the grid-relevant parameters must be available after completion of the first ten operating hours (see "Application for the SMA Grid Guard code" available at <a href="http://www.SMA-Solar.com">www.SMA-Solar.com</a> ).	Section 7.3, page 42
5. Ensure that the country data set has been configured correctly.	Section 9.3, page 57
6. For PV systems in Italy: Start the self-test.	Section 7.4, page 44
7. Make further inverter settings as needed.	Section 9, page 55

### 7.2 Commissioning the Inverter

#### QUALIFIED PERSON

#### Requirements:

- ☐ The AC circuit breaker must be correctly rated and mounted.
- ☐ The inverter must be correctly mounted.
- ☐ All cables must be correctly connected.

**Procedure:**

1. Switch on the AC circuit breaker.
2. Switch on the battery or the load-break switch of the battery (see documentation of the battery manufacturer).
  - ✓ All three LEDs light up briefly. The start-up phase begins.
  - ✗ The red LED is glowing?  
An error has occurred.
    - Rectify the error (see Section 12, page 67).
3. Establish a connection to the user interface of the inverter (see Section 8.1, page 46).

### 7.3 Configuring the Inverter

#### QUALIFIED PERSON

After you have logged onto the user interface as **Installer**, the **Configuring the Inverter** page opens.




Figure 12: Layout of the **Configuring the Inverter** page

Position	Designation	Description
A	Device information	Provides the following information: <ul style="list-style-type: none"><li>• Device name</li><li>• Inverter serial number</li><li>• Inverter firmware version</li></ul>
B	User information	Provides brief information on the listed configuration options
C	Skip configuration	Offers the option of skipping the inverter configuration and going directly to the user interface (not recommended; the inverter cannot be operated without configuration)

Position	Designation	Description
D	Checkbox	Allows you to choose not to have the displayed page displayed again when the user interface is called up again
E	Configuration options	Provides a selection of the various configuration options

Procedure:

On the **Configuring the Inverter** page, three configuration options are available to choose from. Select one of the three options and proceed for the selected option as described below. SMA Solar Technology AG recommends carrying out the configuration with the Installation Assistant. This way, you ensure that all relevant parameters are set for optimal inverter operation.

- Adopt the configuration from a file
- Configuration with the Installation Assistant (recommended)
- Manual configuration

Adopting the Configuration From a File

You can adopt the inverter configuration from a file. To do this, there must be an inverter configuration saved to a file.

Procedure:

1. Select the configuration option **Adopting configuration from a file**.
2. Select **[Browse...]** and select the desired file.
3. Select **[Import file]**.

Configuration with the Installation Assistant (Recommended)




Figure 13: Layout of the installation assistant

Position	Designation	Description
A	Configuration steps	Overview of the installation assistant steps. The number of steps depends on the type of device and the additionally installed modules. The current step is highlighted in blue.

Position	Designation	Description
B	User information	Information about the current configuration step and the setting options of the configuration step.
C	Configuration field	You can make settings in this field.

**Procedure:**

1. Select the configuration option **Configuration with Installation Assistant**.  
☒ The Installation Assistant will open.
2. Follow the Installation Assistant steps and make the settings appropriate for your system.
3. For every setting made in a step, select [**Save and next**].  
☒ In the last step, all made settings are listed in a summary.
4. To save the settings to a file, select [**Export a summary**] and save the file on your computer, tablet PC or smartphone.
5. To correct settings you made, select [**Back**], navigate to the desired step, correct settings and select [**Save and continue**].
6. Once all settings are correct, select [**Next**] in the summary.  
☒ The start page of the user interface opens.

**Manual Configuration**

You can configure the inverter manually by setting the desired parameters.

**Procedure:**

1. Select the configuration option **Manual Configuration**.  
☒ The **Device Parameters** menu on the user interface will open and all available parameter groups of the inverter will be displayed.
2. Select [**Edit parameters**].
3. Select the desired parameter group.  
☒ All available parameters of the parameter group will be displayed.
4. Set the desired parameters.
5. Select [**Save all**].  
☒ The inverter parameters are set.

## 7.4 Starting the Self-Test (For Italy Only)

### QUALIFIED PERSON

The self-test is only required for inverters to be commissioned in Italy. The Italian standard requires that all inverters feeding into the utility grid are equipped with a self-test function in accordance with CEI 0-21. During the self-test, the inverter will consecutively check the reaction times for overvoltage, undervoltage, maximum frequency and minimum frequency.

The self-test changes the upper and lower disconnection values for each protective function on a linear basis for frequency monitoring and voltage monitoring. As soon as the measured value exceeds the permitted disconnection threshold, the inverter disconnects from the utility grid. In this way, the inverter determines the reaction time and checks itself.

After the self-test has been completed, the inverter automatically switches back to feed-in operation, resets the original disconnection conditions and connects to the utility grid. The test takes approximately three minutes.

**Requirements:**

- ☐ The country data set of the inverter must be set to **CEI 0-21 internal**.

**Procedure:**

1. Select the menu **System Configuration**.
2. Select **[Settings]**.
3. Select **[Starting the Self-Test]** in the subsequent context menu.
4. Observe the instructions shown in the dialog and save the report of the self-test, if necessary.

## 8 Using the Inverter User Interface

### 8.1 Establishing a connection to the user interface

#### 8.1.1 Establishing a direct connection via WLAN

##### Requirements:

- ☐ The inverter must be commissioned.
- ☐ A computer, tablet PC or smartphone with WLAN interface must be available.
- ☐ In the case of a computer connection, one of the following web browsers must be installed: Firefox (as of version 25), Internet Explorer (as of version 10), Safari (as of version 7), Opera (as of version 17) or Google Chrome (as of version 30).
- ☐ In the case of a tablet PC or smartphone connection, one of the following web browsers must be installed: Firefox (as of version 25), Safari (as of version iOS 7) or Google Chrome (as of version 29).
- ☐ The personal SMA Grid Guard code of the Installer must be available for the changing of grid-relevant settings after completion of the first ten operating hours (see "Application for SMA Grid Guard Code" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

##### Inverter SSID and IP address and necessary passwords

- Inverter SSID in WLAN: SMA[serial number] (e.g. SMA2130019815)
- Standard WLAN password (usable for initial configuration to completion of the first ten operating hours): SMA 12345
- Device-specific WLAN password (usable for initial configuration to completion of the first ten operating hours): see WPA2-PSK on the type label of the inverter
- Standard IP inverter address for a direct connection via WLAN outside of a local network: 192.168.12.3

##### Importing and exporting files with end devices having an iOS operating system is not possible.


For technical reasons, importing and exporting files (e.g. importing an inverter configuration, saving the current inverter configuration or exporting events) is not possible with mobile end devices having an iOS operating system.

- Use an end device that does not have an iOS operating system for importing and exporting files.

The procedure can be different depending on the terminal devices used (e.g. computer, tablet PC or smartphone). If the procedure described does not apply to your device, establish the direct connection via WLAN as described in the manual of your device.

##### Procedure:

1. If your computer, tablet PC or smartphone has a WPS function:
  - Activate the WPS function on the inverter. To do this, tap on the enclosure lid of the inverter twice.
    - ☒ The blue LED flashes quickly. The WPS function is active.

- Activate the WPS on your device.
  - ☒ The connection with your device will be established automatically. It can take up to 20 seconds for this connection to be established.
- 2. If your computer, tablet PC or smartphone does not have a WPS function:
  - Search for WLAN networks with your device.
  - Select the SSID of the inverter **SMA[serial number]** in the list with the found WLAN networks.
  - Enter the inverter WLAN password. Within the first 10 operating hours, you must use the standard WLAN password **SMA12345**. After the first 10 operating hours, you must use the device-specific WLAN password (WPA2-PSK) of the inverter. The WLAN password (WPA2-PSK) is printed on the type label.
- 3. Enter the IP address **192.168.12.3** or, if your device supports mDNS services, **SMA[serial number].local** in the address line of the web browser and press the enter key.
- 4.  **Web browser signals a security vulnerability**

After the IP address has been confirmed by pressing the enter key, a message might appear indicating that the connection to the user interface of the inverter is not secure. SMA Solar Technology AG guarantees that calling up the user interface is secure.

  - Continue loading the user interface.

☒ The login page of the user interface opens.

## 8.1.2 Establishing a Direct Connection via Ethernet

### Requirements:

- ☐ The inverter must be commissioned.
- ☐ A computer with an Ethernet interface must be available.
- ☐ The inverter must be connected directly to a computer.
- ☐ One of the following web browsers must be installed: Firefox (as of version 25), Internet Explorer (as of version 10), Safari (as of version 7), Opera (as of version 17) or Google Chrome (as of version 30).
- ☐ The personal SMA Grid Guard code of the Installer must be available for the changing of grid-relevant settings after completion of the first ten operating hours (see certificate "Application for SMA Grid Guard Code" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

### IP address of the inverter


- Standard inverter IP address for direct connection via Ethernet: 169.254.12.3

### Importing and exporting files with end devices having an iOS operating system is not possible.

For technical reasons, importing and exporting files (e.g. importing an inverter configuration, saving the current inverter configuration or exporting events) is not possible with mobile end devices having an iOS operating system.

- Use an end device that does not have an iOS operating system for importing and exporting files.

**Procedure:**

1. Open the web browser of your device, enter the IP address **169.254.12.3** in the address line and press the enter key.
  2.  **Web browser signals a security vulnerability**  
 After the IP address has been confirmed by pressing the enter key, a message might appear indicating that the connection to the user interface of the inverter is not secure. SMA Solar Technology AG guarantees that calling up the user interface is secure.
    - Continue loading the user interface.
- ☒ The login page of the user interface opens.

### 8.1.3 Establishing a Connection via Ethernet in the local network

#### New IP address for connecting with a local network

If the inverter is connected to a local network via a network cable (e.g. via a router), the inverter will receive a new IP address. Depending on the type of configuration, the new IP address will be assigned automatically by the DHCP server (router) or manually by you. Upon completion of the configuration, the inverter is only reachable via this new IP address or the alternative addresses.

Access addresses of the inverter:

- Generally applicable access address, e.g. for android products: IP address manually assigned or assigned by the DHCP server (router) (identification via network scanner software or router manual).
- Alternative access address for Apple products: SMA[serial number].local (e.g. SMA2130019815.local)
- Alternative access address for certain Windows products: SMA[serial number] (e.g. SMA2130019815)

**Requirements:**

- ☐ The inverter must be connected to the local network via a network cable (e.g. via a router).
- ☐ The inverter must be integrated in the local network.
- ☐ A computer, tablet PC or smartphone must be available and the computer, tablet PC or smartphone must be connected with the network to which the inverter is also connected.
- ☐ In the case of a computer connection, one of the following web browsers must be installed: Firefox (as of version 25), Internet Explorer (as of version 10), Safari (as of version 7), Opera (as of version 17) or Google Chrome (as of version 30).
- ☐ In the case of a tablet PC or smartphone connection, one of the following web browsers must be installed: Firefox (as of version 25), Safari (as of version iOS 7) or Google Chrome (as of version 29).
- ☐ The personal SMA Grid Guard code of the Installer must be available for the changing of grid-relevant settings after completion of the first ten feed-in hours (see certificate "Application for SMA Grid Guard Code" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).



**i** **Importing and exporting files with end devices having an iOS operating system is not possible.**

For technical reasons, importing and exporting files (e.g. importing an inverter configuration, saving the current inverter configuration or exporting events) is not possible with mobile end devices having an iOS operating system.

- Use an end device that does not have an iOS operating system for importing and exporting files.

**Procedure:**

1. Open the web browser of your device, enter the IP address of the inverter in the address line of the web browser and press the enter key.

2. **i** **Web browser signals a security vulnerability**

After the IP address has been confirmed by pressing the enter key, a message might appear indicating that the connection to the user interface of the inverter is not secure. SMA Solar Technology AG guarantees that calling up the user interface is secure.

- Continue loading the user interface.

- ☒ The login page of the user interface opens.

## 8.2 Logging In and Out of the User Interface

After a connection to the user interface of the inverter has been established, the login page opens. Log onto the user interface as described below.

**i** **Usage of cookies**

For the correct display of the user interface, cookies are required. The cookies are used for convenience only. By using this user interface you agree to the placement of cookies.

### Log in as installer or user for the first time

**i** **Password for PV systems that are registered in a communication product**

The password for the user group **Installer** is also the system password. If you assign a password for the user group **Installer** via the user interface of the inverter, the password must match the PV system password. If the new password for logging onto the user interface does not match the system password in the communication product, the inverter cannot be reached by the communication product.

- A uniform password is assigned for all Speedwire devices in the PV system.

**Procedure:**

1. In the drop-down list **Language**, select the desired language.
2. In the **User group** drop-down list, select the entry **Installer** or **User**.
3. In the **New password** field, enter a new password for the selected user group.
4. In the **Repeat password** field, enter the new password again.
5. Select **Login**.

- ☒ The **Configuring the Inverter** page or the user interface start page opens.

**Log in as the User or Installer**

1. In the drop-down list **Language**, select the desired language.
2. In the **User group** drop-down list, select the entry **Installer** or **User**.
3. Enter the password in the field **Password**.
4. Select **Login**.

☒ The start page of the user interface opens.

**Log Out as the User or Installer**

1. On the right-hand side of the menu bar, select the menu **User Settings**.
2. In the subsequent context menu, select [**Logout**].

☒ The login page of the user interface opens. The logout was successful.

8.3 Start Page Design of the User Interface




Figure 14: Start Page Design of the User Interface

Position	Designation	Description
A	Menu	<p>Provides the following functions:</p> <ul style="list-style-type: none"> <li>• <b>Home</b> Opens the user interface homepage</li> <li>• <b>Instantaneous values</b> Current measured values of the inverter</li> <li>• <b>Device Parameters</b> The various operating parameters of the inverter can be viewed and configured here depending on the user group.</li> <li>• <b>Events</b> All events that have occurred in the selected time period are displayed here. The event types are <b>Information</b>, <b>Warning</b> and <b>Error</b>. Currently existing events of the types <b>Error</b> and <b>Warning</b> will be additionally displayed in the <b>Device status</b> viewlet. However, only the higher-priority event is displayed. If, for example, there is a Warning and an Error present at the same time, only the Error will be displayed.</li> <li>• <b>Device configuration</b> The following settings for the inverter can be performed here. The selection available is dependent on which user group you are logged in as and the operating system of the device with which the user interface has been called up. <ul style="list-style-type: none"> <li>- Changing device names</li> <li>- Updating firmware (not available with devices having an iOS operating system)</li> <li>- Saving a configuration to file (not available with devices having an iOS operating system)</li> <li>- Loading a configuration from a file (not available with devices having an iOS operating system)</li> </ul> </li> </ul>
B	User settings	<p>Provides the following functions, depending on the user group logged in:</p> <ul style="list-style-type: none"> <li>• Start the installation assistant</li> <li>• SMA Grid Guard login</li> <li>• Logout</li> </ul>
C	Help	<p>Provides the following functions:</p> <ul style="list-style-type: none"> <li>• Displaying information on Open Source licenses used</li> <li>• Link to the website of SMA Solar Technology AG</li> </ul>

Position	Designation	Description
D	Status bar	<p>Displays the following information:</p> <ul style="list-style-type: none"> <li>• Inverter serial number</li> <li>• Inverter firmware version</li> <li>• IP address of the inverter within the local network and/or IP address of the inverter during WLAN connection</li> <li>• User group logged in</li> <li>• Date and device time of the inverter</li> </ul>
E	State of charge	Chronological sequence of the state of charge (SOC) of the battery
F	Status display	<p>The various areas display information on the current status of the system.</p> <ul style="list-style-type: none"> <li>• <b>Device status</b> Displays whether the inverter and/or the battery is/are currently in a fault-free operating state or whether there is an event type <b>Error</b> or <b>Warning</b> present.</li> <li>• <b>Feed-in management</b> Displays whether the inverter is currently limiting its active power.</li> <li>• <b>Nominal energy throughput of the battery</b> Indicates how much energy has been charged to the battery and how much has been discharged from the battery.</li> <li>• <b>Battery</b> Displays the following information: <ul style="list-style-type: none"> <li>- Operating status of battery</li> <li>- Current battery state of charge</li> <li>- Current battery charging power</li> </ul> </li> <li>• <b>Energy exchange at the grid-connection point</b> Indicates how much energy was obtained from the utility grid to supply the household and how much the PV system fed in.</li> <li>• <b>Power at the grid-connection point</b> Indicates which power is currently fed in or obtained at the grid-connection point.</li> </ul>

## 8.4 Changing the Password

The password for the inverter can be changed for both user groups. Furthermore, the user group **Installer** can change the password for the user group **User** as well as its own password.

### PV systems registered in a communication product

With PV systems that are registered in a communication product (e.g. Sunny Portal, Sunny Home Manager), you can also assign a new password for the user group **Installer** via the communication product. The password for the user group **Installer** is also the system password. If you assign a password for the user group **Installer** via the user interface of the inverter that does not correspond to the system password in the communication product, the inverter can no longer be reached by the communication product.

- Ensure that the password for the user group **Installer** is the same as the system password in the communication product.

#### Procedure:

1. Activate the user interface (see Section 8.1, page 46).
2. Log into the user interface (see Section 8.2, page 49).
3. Call up the menu **Device Parameters**.
4. Select **[Edit parameters]**.
5. In the parameter group **User Rights > Access Control** change the password of the desired user group.
6. Select **[Save all]** to save the changes.

## 9 Configuration of the Inverter

### 9.1 Changing Operating Parameters

The operating parameters of the inverter are set to certain values by default. You can change the operating parameters to optimize the performance of the inverter.

This section describes the basic procedure for changing operating parameters. Always change operating parameters as described in this section. Some function-sensitive parameters can only be viewed by qualified persons and can only be changed by qualified persons by entering the personal SMA Grid Guard code.

#### **No configuration via Sunny Explorer**

Sunny Explorer does not support the configuration of inverters with their own user interface. The inverter can be detected via Sunny Explorer, however it is expressly not recommended to use Sunny Explorer to configure this inverter. SMA Solar Technology AG does not accept liability for missing or incorrect data and possibly resulting yield losses.

- Use the user interface for the configuration of the inverter.

#### **Requirements:**

- ☐ The changes to the grid-relevant parameters must be approved by the grid operator.
- ☐ When changing grid-relevant parameters, the SMA Grid Guard code must be available (see "Application for SMA Grid Guard Code" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).
- ☐ Modifications of factory-set parameters for the battery configuration must be approved by the battery manufacturer.

#### **Procedure:**

1. Activate the user interface (see Section 8.1, page 46).
  2. Log into the user interface (see Section 8.2, page 49).
  3. Call up the menu **Device Parameters**.
  4. Select [**Edit parameters**].
  5. Log in using the SMA Grid Guard code to change those parameters designated by a lock (only for installers):
    - Select the menu **User Settings** (see Section 8.3, page 51).
    - In the subsequent context menu, select [**SMA Grid Guard login**].
    - Enter the SMA Grid Guard code and select [**Login**].
  6. Expand the parameter group that contains the parameter which is to be configured.
  7. Change the desired parameters.
  8. Select [**Save all**] to save the changes.
- ☒ The inverter parameters are set.

**i** **Accepting the settings**

Saving the made settings is indicated by an hourglass symbol on the user interface. If the DC voltage is sufficient, the data is transferred directly to the inverter and accepted. If the DC voltage is too low (e.g. when the battery is switched off), the settings are saved, but they cannot be directly transferred to or accepted by the inverter. As long as the inverter has not yet received and accepted the settings, the hourglass symbol will continue to be displayed on the user interface. The settings will be accepted when there is sufficient DC voltage applied and the inverter restarts. As soon as the hourglass symbol appears on the user interface, the settings have been saved. The settings will not be lost. You can log off of the user interface and leave the system.

**9.2 Starting the Installation Assistant**

**⚠ QUALIFIED PERSON**

The installation assistant leads you step-by-step through the steps necessary for the initial configuration of the inverter.

**Layout of the installation assistant**




Figure 15: Layout of the installation assistant

Position	Designation	Description
A	Configuration steps	Overview of the installation assistant steps. The number of steps depends on the type of device and the additionally installed modules. The current step is highlighted in blue.
B	User information	Information about the current configuration step and the setting options of the configuration step.
C	Configuration field	You can make settings in this field.



**Requirement:**

- ☐ When configuring after completion of the first ten operating hours, the SMA Grid Guard code must be available (see "Application for SMA Grid Guard Code" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

**Procedure:**

1. Activate the user interface (see Section 8.1, page 46).
  2. Log in as **Installer**.
  3. Select the menu **User Settings** (see Section 8.3, page 51) on the start page of the user interface.
  4. In the context menu, select [**Start the installation assistant**].
- ☒ The Installation Assistant will open.

## 9.3 Configuring the Country Data Set

### QUALIFIED PERSON

By default, the inverter is set to a universally valid country data set. You can adjust the country data set for the installation site retroactively.

#### The country data set must be set correctly.

If you select a country data set which is not valid for your country and purpose, it can cause a disturbance in the PV system and lead to problems with the grid operator. When selecting the country data set, you must always observe the locally applicable standards and directives as well as the properties of the PV system (e.g. PV system size, grid-connection point).

- If you are not sure which country data set is valid for your country or purpose, contact your grid operator for information on which country data set is to be configured.

The basic procedure for changing operating parameters is explained in another section (see Section 9.1 "Changing Operating Parameters", page 55).

**Procedure:**

- In the parameter group **Grid monitoring > Grid monitoring** select the parameter **Set country standard** and set the required country data set.

## 9.4 Configuring the Modbus Function

### QUALIFIED PERSON

The Modbus interface is deactivated by default and the communication ports **502** set. In order to access SMA inverters with SMA Modbus® or SunSpec® Modbus®, the Modbus interface must be activated. After activating the interface, the communication ports of both IP protocols can be changed.

For information on commissioning and configuration of the Modbus interface, see the Technical Information "SMA Modbus® Interface" or in the Technical Information "SunSpec® Modbus® Interface" at [www.SMA-Solar.com](http://www.SMA-Solar.com).

For information on which Modbus registers are supported, see the Technical Descriptions "SMA Modbus® Interface" or "SunSpec® Modbus® Interface" at [www.SMA-Solar.com](http://www.SMA-Solar.com).

### **Data security during activated Modbus interface**

If you activate the Modbus interface, there is a risk that unauthorized users may access and manipulate the data or devices in your PV system.

- Take appropriate protective measures such as:
  - Set up a firewall.
  - Close unnecessary network ports.
  - Only enable remote access via VPN tunnel.
  - Do not set up port forwarding at the communication port in use.
  - In order to deactivate the Modbus interface, reset the inverter to default settings.

### **Deactivate the dynamic active power limitation for the PV inverters when controlled via Modbus**

If the PV inverters and the battery inverter are controlled in a PV system via Modbus, the dynamic active power limitation of the PV inverters must be deactivated.

#### **Procedure:**

- Activate the Modbus interface and adjust the communication ports if necessary (see the Technical Information "SMA Modbus® Interface" or "SunSpec® Modbus® Interface" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

## **9.5 Saving the Configuration in a File**

You can save the current configuration of the inverter in a file. You can use this file as a data backup for this inverter and then import this file into this inverter again or another inverter to configure the inverter. When saving, only the device parameters will be saved, not any passwords.

#### **Procedure:**

1. Activate the user interface (see Section 8.1, page 46).
2. Log into the user interface (see Section 8.2, page 49).
3. Select the menu **System Configuration**.
4. Select **[Settings]**.
5. In the context menu, select **[Saving the configuration in a file]**.
6. Follow the instructions in the dialog.

## **9.6 Adopting a Configuration from a File**

### **QUALIFIED PERSON**

To configure the inverter, you can adopt the configuration from a file. To be able to do this, you must first save the configuration of another inverter in a file (see Section 9.5 "Saving the Configuration in a File", page 58). When saving, only the device parameters will be adopted, not any passwords.

**Requirements:**

- ☐ The SMA Grid Guard code must be available (see "Application for SMA Grid Guard Code" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).
- ☐ Changes to grid-relevant parameters must be approved by the responsible grid operator.

**Procedure:**

1. Activate the user interface (see Section 8.1, page 46).
2. Log into the user interface as an **Installer**.
3. Select the menu **System Configuration**.
4. Select **[Settings]**.
5. In the context menu, select **[Adopting the configuration from a file]**.
6. Follow the instructions in the dialog.

## 9.7 Activate WPS Function

- Tap on the enclosure lid of the inverter twice.
  - ☒ The blue LED flashes quickly for approx. two minutes.

## 9.8 Switching WLAN On and Off

The inverter is equipped with an activated WLAN interface as standard. If you do not want to use WLAN, you can switch the WLAN function off and switch it on again whenever needed. In doing so, you can switch the WLAN direct connection and the WLAN connection in the local network on independently of each other.

### Switching on the WLAN function only possible via Ethernet connection

If you switch off both the WLAN function for the direct connection and for the connection in the local network, access to the inverter user interface and therefore reactivation of the WLAN interface is only possible via an Ethernet connection.

The basic procedure for changing operating parameters is explained in another section (see Section 9.1 "Changing Operating Parameters", page 55).

### Switching WLAN Off

If you would like to switch the WLAN function off completely, you must switch off both the direct connection and the connection in the local network.

**Procedure:**

- To switch off the direct connection in the parameter group **PV system communication > WLAN**, select the parameter **Soft-access-point is turned on** and set this to **No**.
- To switch off the connection in the local network in the parameter group **PV system communication > WLAN**, select the parameter **WLAN is turned on** and set this to **No**.

### Switching WLAN On

If you have switched the WLAN function for direct connection or for connection in the local network off, you can switch the WLAN function back on in accordance with the following procedure.

**Requirement:**

- ☐ If the WLAN function was previously switched off completely, the inverter must be connected to a computer or router via Ethernet.

**Procedure:**

- To switch on the WLAN direct connection, in the parameter group **PV system communication > WLAN**, select the parameter **Soft-access-point is turned on** and set this to **Yes**.
- To switch on the WLAN connection in the local network, in the parameter group **System communication > WLAN**, select the parameter **WLAN is turned on** and set this to **Yes**.

## 9.9 Activating the Receipt of Control Signals (Only for Italy)

### QUALIFIED PERSON

In order for PV systems in Italy to receive control commands from the grid operator, set the following parameters.

The basic procedure for changing operating parameters is explained in another section (see Section 9.1 "Changing Operating Parameters", page 55).

Parameters	Value/range	Resolution	Default
Application ID	0 to 16384	1	16384
GOOSE-Mac address	01:0C:CD:01:00:00 to 01:0C:CD:01:02:00	1	01:0C:CD:01:00:00

**Procedure:**

1. Select the parameter group **External communication > IEC 61850 configuration**.
  2. In the field **Application ID**, enter the application ID of the grid operator gateway. You will receive this value from your grid operator. You can enter a value between 0 and 16384. The value 16384 indicates "deactivated".
  3. In the field **GOOSE-Mac address**, enter the MAC address of the grid operator gateway from which the inverter is to receive the control commands. You will receive this value from your grid operator.
- ☒ The receipt of control signals from the grid operator is activated.

## 9.10 Deactivating Grounding Conductor Monitoring

### QUALIFIED PERSON

If the inverter is to be installed in an IT network or another grid configuration in which deactivation of the grounding conductor monitoring is required, deactivate the grounding conductor monitoring as follows.

The basic procedure for changing operating parameters is explained in another section (see Section 9.1 "Changing Operating Parameters", page 55).

**Procedure:**

- In the parameter group **Grid monitoring** > **Grid monitoring** set the parameter **PE connection monitoring** to **Off**.

## 9.11 Configuring the Energy Meter

### QUALIFIED PERSON

You can add an energy meter to your PV system or replace an existing energy meter.

The basic procedure for changing operating parameters is explained in another section (see Section 9.1 "Changing Operating Parameters", page 55).

#### Removing a detected energy meter from the PV system

If only one energy meter is detected by the inverter, this will be added to the PV system automatically. Removal via the menu **Device configuration** is not possible in this case. To remove the energy meter from the PV system, proceed as follows:

- In the parameter group **PV system communication** > **Measured values** > **Meter on Speedwire** set the parameter **Serial number** to any number (e.g. **1**). In this way, instead of the energy meter detected, the PV system will add a fictitious energy meter to which the inverter cannot establish communication.

**Procedure:**

1. Activate the user interface (see Section 8.1, page 46).
2. Log in as **Installer**.
3. Start the installation assistant (see Section 9.2, page 56).
4. In the context menu, select [**Start the installation assistant**].
5. Select [**Save and next**] until you get to the step **Meter configuration**.
6. Add or replace the desired energy meter.

## 9.12 Configuring Feed-In Management

### QUALIFIED PERSON

If required by the grid operator, the inverter can provide grid management services. You can configure these via the inverter feed-in management. Coordinate the configuration of the feed-in management with your grid operator beforehand.

The basic procedure for changing operating parameters is explained in another section (see Section 9.1 "Changing Operating Parameters", page 55).

**Procedure:**

1. Activate the user interface (see Section 8.1, page 46).
2. Log into the user interface as an **Installer**.
3. On the right-hand side of the menu bar, select the menu **User Settings** (see Section 8.3 "Start Page Design of the User Interface", page 51).
4. In the subsequent context menu, select [**Start the installation assistant**].

5. Select [**Save and next**] until you arrive in the menu **Feed-in management**.
6. Configure the feed-in management as desired.


## 10 Disconnecting the Inverter from Voltage Sources

### ⚠ QUALIFIED PERSON


Prior to performing any work on the inverter, always disconnect it from all voltage sources as described in this section. Always adhere to the prescribed sequence.

#### Procedure:


1. Disconnect the AC circuit breaker and secure it against reconnection.
2. If the battery has a load-break switch, then switch it off (see the documentation of the battery manufacturer).
3. Unscrew the swivel nuts from the cable glands on the connection cap.




4. Unscrew the screws of the connection cap with a Torx screwdriver (TX 20) and remove the connection cap towards the bottom.




5. Ensure that no voltage is present between **L** and **N** and **L** and  $\oplus$  on the connecting terminal plate for the AC connection using a suitable measuring device. To do so, insert the test probe (maximum diameter: 2 mm) into each round opening of the connecting terminal plate.
6. Release and disconnect the connecting terminal plate using the sliders located at the side.




7. Remove the plug with the battery communication cable.




8. Release and remove the plug of the network cable.



9. Use a current clamp to ensure that no current is present in the DC conductors.




10. Release and remove the DC connectors. To do this, insert a flat-blade screwdriver or an angled screwdriver (blade width: 3.5 mm) into one of the slide slots and pull the DC connectors out in a downward direction. Do not pull on the cable.





11. Ensure that no voltage is present at the DC inputs on the inverter using a suitable measuring device.



## 11 Cleaning the Inverter

***NOTICE*****Damage to the inverter due to the use of cleaning agents**

- If the inverter is dirty, clean the enclosure, the enclosure lid, the type label and the LEDs using only clean water and a cloth.
- Ensure that the inverter is free of dust, foliage and other dirt.

## 12 Troubleshooting

### 12.1 Forgotten Password

If you have forgotten the password for the inverter, you can unlock the inverter with a Personal Unlocking Key (PUK). For each inverter, there is one PUK for each user group (**User** and **Installer**). Useful hint: With PV systems in Sunny Portal, you can also assign a new password via Sunny Portal for the user group **Installer**. The password for the user group **Installer** is the same as the system password in Sunny Portal.

#### Procedure:

1. Request PUK (application form available at [www.SMA-Solar.com](http://www.SMA-Solar.com)).
2. Activate the user interface (see Section 8.1, page 46).
3. Enter the PUK instead of the password into the field **Password**.
4. Call up the menu **Device Parameters**.
5. Select **[Edit parameters]**.
6. In the parameter group **User Rights > Access Control** change the password of the desired user group.
7. Select **[Save all]** to save the changes.



#### **PV Systems in Sunny Portal**

The password for the user group **Installer** is also the system password for the PV system in Sunny Portal. Changing the password of the user group **Installer** can lead to the inverter no longer being able to be reached by Sunny Portal.

- Assign the changed password of the user group **Installer** as the new system password in Sunny Portal (see the Sunny Portal user manual at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

## 12.2 Event Messages

Event number	Message, cause and corrective measures
101 to 105	<div><b>⚠ QUALIFIED PERSON</b></div> <p><b>Grid fault</b></p> <p>The grid voltage or grid impedance at the connection point of the inverter is too high. The inverter has disconnected from the utility grid.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Ensure that the correct country data set has been configured (see Section 9.3, page 57).</li> <li>• Check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.</li> </ul> <p>If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.</p> <p>If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service (see Section 16 "Contact", page 100).</p>
202 to 206	<div><b>⚠ QUALIFIED PERSON</b></div> <p><b>Grid fault</b></p> <p>The utility grid has been disconnected, the AC cable is damaged or the grid voltage at the connection point of the inverter is too low. The inverter has disconnected from the utility grid.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Make sure that the circuit breaker is switched on.</li> <li>• Ensure that the AC cable is not damaged and that it is connected correctly.</li> <li>• Ensure that the country data set has been configured correctly.</li> <li>• Check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.</li> </ul> <p>If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.</p> <p>If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service (see Section 16 "Contact", page 100).</p>

Event number	Message, cause and corrective measures
302	<p><b>Active power limited AC voltage</b></p> <p>The inverter has reduced its power due to a too-high grid voltage to ensure grid stability.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• If possible, check the grid voltage and observe how often fluctuations occur. If fluctuations occur frequently and this message is displayed often, contact the grid operator and request approval to change the operating parameters of the inverter. If the grid operator gives his approval, discuss any changes to the operating parameters with Service (see Section 16 "Contact", page 100).</li> </ul>
401 to 404	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Grid fault</b></p> <p>The inverter has disconnected from the utility grid. A stand-alone grid or a very large change in the power frequency was detected.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Check the grid connection for significant short-term frequency fluctuations.</li> </ul>
501	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Grid fault</b></p> <p>The power frequency is not within the permissible range. The inverter has disconnected from the utility grid.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• If possible, check the power frequency and observe how often fluctuations occur.</li> </ul> <p>If fluctuations occur frequently and this message is displayed often, contact the grid operator and request approval to change the operating parameters of the inverter.</p> <p>If the grid operator gives his approval, discuss any changes to the operating parameters with Service (see Section 16 "Contact", page 100).</p>

Event number	Message, cause and corrective measures
507	<div data-bbox="311 185 598 220"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="288 236 649 263"><b>Active power limited AC frequency</b></p> <p data-bbox="288 271 985 327">The inverter has reduced its power due to a too-high power frequency to ensure grid stability.</p> <p data-bbox="288 335 508 359"><b>Corrective measures:</b></p> <ul data-bbox="311 367 1005 539" style="list-style-type: none"> <li>• If possible, check the power frequency and observe how often fluctuations occur. If fluctuations occur frequently and this message is displayed often, contact the grid operator and request approval to change the operating parameters of the inverter. If the grid operator gives his approval, discuss any changes to the operating parameters with Service (see Section 16 "Contact", page 100).</li> </ul>
601	<div data-bbox="311 552 598 587"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="288 603 392 630"><b>Grid fault</b></p> <p data-bbox="288 638 976 694">The inverter has detected an excessively high proportion of direct current in the grid current.</p> <p data-bbox="288 702 508 726"><b>Corrective measures:</b></p> <ul data-bbox="311 734 967 826" style="list-style-type: none"> <li>• Check the grid connection for direct current.</li> <li>• If this message is displayed frequently, contact the grid operator and check whether the monitoring threshold on the inverter can be raised.</li> </ul>
701	<div data-bbox="311 839 598 874"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="288 890 676 917"><b>Frq. not permitted &gt; Check parameter</b></p> <p data-bbox="288 925 990 981">The power frequency is not within the permissible range. The inverter has disconnected from the utility grid.</p> <p data-bbox="288 989 508 1013"><b>Corrective measures:</b></p> <ul data-bbox="311 1021 1008 1236" style="list-style-type: none"> <li>• If possible, check the power frequency and observe how often fluctuations occur. If fluctuations occur frequently and this message is displayed often, contact the grid operator and request approval to change the operating parameters of the inverter. If the grid operator gives his approval, discuss any changes to the operating parameters with Service (see Section 16 "Contact", page 100).</li> </ul>
901	<div data-bbox="311 1254 598 1289"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="288 1305 674 1332"><b>No PE connection &gt; Check connection</b></p> <p data-bbox="288 1340 766 1364">The grounding conductor is not correctly connected.</p> <p data-bbox="288 1372 508 1396"><b>Corrective measures:</b></p> <ul data-bbox="311 1404 960 1460" style="list-style-type: none"> <li>• Ensure that the grounding conductor is correctly connected (see Section 6.2.2 "Connecting the Inverter to the Utility Grid", page 27).</li> </ul>





Event number	Message, cause and corrective measures
1001	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>L/N swapped &gt; Check connection</b>  The connection of L and N is swapped.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Ensure that L and N are correctly connected (see Section 6.2.2 "Connecting the Inverter to the Utility Grid", page 27).</li> </ul>
1101	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Installation fault &gt; Check connection</b>  A second line conductor is connected to N.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Connect the neutral conductor to N (see Section 6.2.2 "Connecting the Inverter to the Utility Grid", page 27).</li> </ul>
1302	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Waiting for grid voltage &gt; Installation failure grid connection &gt; Check grid and fuses</b>  L or N not connected.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Ensure that L and N are connected (see Section 6.2.2 "Connecting the Inverter to the Utility Grid", page 27).</li> <li>• Ensure that the AC cable is not damaged and that it is connected correctly (see Section 6.2.2 "Connecting the Inverter to the Utility Grid", page 27).</li> <li>• Make sure that the circuit breaker is switched on.</li> </ul>
1501	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Reconnection fault grid</b>  The changed country data set or the value of a parameter you have set does not correspond to the local requirements. The inverter cannot connect to the utility grid.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Ensure that the country data set has been configured correctly. To do this, select the parameter <b>Set country standard</b> and check the value.</li> </ul>

Event number	Message, cause and corrective measures
3301	<div data-bbox="314 185 598 220"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 236 490 260"><b>Unstable operation</b></p> <p data-bbox="292 272 1001 325">There is not enough power at the DC input of the inverter for stable operation. The inverter cannot connect to the utility grid.</p> <p data-bbox="292 336 507 360"><b>Corrective measures:</b></p> <ul data-bbox="311 368 852 395" style="list-style-type: none"> <li>• Ensure that the correct battery type has been configured.</li> </ul>
3401	<div data-bbox="314 411 598 446"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 462 695 486"><b>DC overvoltage &gt; Disconnect generator</b></p> <p data-bbox="292 499 818 523">Overvoltage at the DC input. This can destroy the inverter.</p> <p data-bbox="292 534 507 558"><b>Corrective measures:</b></p> <ul data-bbox="311 566 981 842" style="list-style-type: none"> <li>• <b>Immediately</b> disconnect the inverter from all voltage sources (see Section 10, page 63).</li> <li>• Check whether the DC voltage is below the maximum input voltage of the inverter. If the DC voltage is below the maximum DC voltage of the inverter, reconnect the DC connectors to the inverter.</li> <li>• If the DC voltage is above the maximum DC voltage of the inverter, ensure that the correct battery has been selected.</li> <li>• If this message is repeated frequently, contact the Service (see Section 16 "Contact", page 100).</li> </ul>
3501	<div data-bbox="314 858 598 893"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 909 658 933"><b>Insulation failure &gt; Check generator</b></p> <p data-bbox="292 946 801 970">The inverter has detected a ground fault on the DC side.</p> <p data-bbox="292 981 507 1005"><b>Corrective measures:</b></p> <ul data-bbox="311 1013 810 1042" style="list-style-type: none"> <li>• Check the battery and DC cabling for ground faults.</li> </ul>
3601	<div data-bbox="314 1058 598 1093"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 1109 695 1133"><b>High discharge curr. &gt; Check generator</b></p> <p data-bbox="292 1145 947 1198">The leakage current of the inverter and the battery is too high. There is a ground fault, a residual current or a malfunction.</p> <p data-bbox="292 1209 981 1289">The inverter interrupts parallel grid operation immediately after exceeding a threshold. When the fault is eliminated, the inverter automatically reconnects to the utility grid.</p> <p data-bbox="292 1300 507 1324"><b>Corrective measures:</b></p> <ul data-bbox="311 1332 810 1356" style="list-style-type: none"> <li>• Check the battery and DC cabling for ground faults.</li> </ul>



Event number	Message, cause and corrective measures
3701	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Resid.curr.too.high &gt; Check generator</b></p> <p>The inverter detected a residual current due to brief grounding of the battery or the DC cabling.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Check the battery and DC cabling for ground faults.</li> </ul>
3801	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>DC overcurrent &gt; Check generator</b></p> <p>Overcurrent at the DC input. The inverter briefly interrupts feed-in operation.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• If this message is displayed frequently, ensure that the battery has been correctly connected and that the correct battery has been selected.</li> </ul>
6607 to 6608	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Self-diagnosis &gt; Battery overcurrent</b></p> <p>The battery detected an overcurrent on the DC side.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Ensure that the battery is correct.</li> <li>• If this message is displayed frequently, contact the Service (see Section 16 "Contact", page 100).</li> </ul>
6701 to 6702	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Communication disturbed</b></p> <p>Error in the communication processor. The inverter is still in parallel grid operation.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• If this message is displayed frequently, contact the Service (see Section 16 "Contact", page 100).</li> </ul>
7201 to 7202	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Data stor. not poss.</b></p> <p>Internal error. The inverter is still in parallel grid operation.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Contact the Service (see Section 16 "Contact", page 100).</li> </ul>

Event number	Message, cause and corrective measures
7303	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Update main CPU failed</b> The cause must be determined by the Service.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Contact the Service (see Section 16 "Contact", page 100).</li> </ul>
7324	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Wait for update conditions</b> The testing of the update conditions was not successful. The firmware update package is not suitable for this inverter.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Retry update.</li> <li>• Ensure that the selected update file is suitable for this inverter.</li> <li>• If this message is displayed again, contact the Service (see Section 16 "Contact", page 100).</li> </ul>
7331	<p><b>Update transport started</b> Update file is being copied.</p>
7332	<p><b>Update transport successful</b> Update file was copied successfully to the inverter's internal memory.</p>
7333	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Update transport failed</b> Update file could not be copied to the inverter's internal memory. In the event of connection with the inverter via WLAN, a poor connection quality can be the cause.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Retry update.</li> <li>• For WLAN connection: Improve the WLAN connection quality (e.g. via WLAN repeater) or establish connection with the inverter via Ethernet.</li> <li>• If this message is displayed again, contact the Service (see Section 16 "Contact", page 100).</li> </ul>

Event number	Message, cause and corrective measures
7337	<div> <b>QUALIFIED PERSON</b></div> <p><b>Update BMS failed</b> The firmware of the battery could not be updated.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Make sure that the correct update file was used.</li><li>• Retry update.</li><li>• If this message is displayed again, contact the Service (see Section 16 "Contact", page 100).</li></ul>
7341	<p><b>Update Bootloader</b> The inverter is performing a bootloader update.</p>
7342	<div> <b>QUALIFIED PERSON</b></div> <p><b>Update Bootloader failed</b> The bootloader update failed.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Retry update.</li><li>• If this message is displayed again, contact the Service (see Section 16 "Contact", page 100).</li></ul>
7347	<div> <b>QUALIFIED PERSON</b></div> <p><b>Incompatible file</b> The configuration file is not suitable for this inverter.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Ensure that the selected configuration file is suitable for this inverter.</li><li>• Retry import.</li></ul>
7348	<div> <b>QUALIFIED PERSON</b></div> <p><b>Incorrect file format</b> The configuration file is not of the required format or is damaged.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Ensure that the selected configuration file is of the required format and is not damaged.</li><li>• Retry import.</li></ul>

Event number	Message, cause and corrective measures
7349	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Incorrect login rights for configuration file</b></p> <p>The user group logged in does not have the user rights necessary to be able to import a configuration.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Log in as <b>Installer</b>.</li> <li>• Import configuration file again.</li> </ul>
7350	<p><b>Transfer of a configuration file has started</b></p> <p>The configuration file is being transferred.</p>
7351	<p><b>Update WLAN</b></p> <p>The inverter is updating the WLAN module.</p>
7352	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Update of WLAN not successful</b></p> <p>The update of the WLAN module failed.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Retry update.</li> <li>• If this message is displayed again, contact the Service (see Section 16 "Contact", page 100).</li> </ul>
7353	<p><b>Update time zone database</b></p> <p>The inverter is updating the time zone database.</p>
7354	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Update of time zone database not successful</b></p> <p>The update of the time zone database failed.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Retry update.</li> <li>• If this message is displayed again, contact the Service (see Section 16 "Contact", page 100).</li> </ul>
7355	<p><b>Update WebUI</b></p> <p>The inverter is updating the inverter user interface.</p>

Event number	Message, cause and corrective measures
7356	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Update of the WebUI not successful</b></p> <p>The update of the inverter user interface failed.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Retry update.</li><li>• If this message is displayed again, contact the Service (see Section 16 "Contact", page 100).</li></ul>
8003	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Active power limited derating</b></p> <p>The inverter has reduced its power output for more than ten minutes due to excessive temperature.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Clean the cooling fins on the rear of the enclosure and the air ducts on the top using a soft brush.</li><li>• Ensure that the inverter has sufficient ventilation.</li><li>• Ensure that the ambient temperature 40°C has not been exceeded.</li><li>• Ensure that the inverter is not exposed to direct solar irradiation.</li></ul>
9002	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>SMA Grid Guard code invalid</b></p> <p>The SMA Grid Guard code entered is incorrect. The operating parameters are still protected and cannot be changed.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Enter the correct SMA Grid Guard code.</li></ul>
9003	<p><b>Grid parameter locked</b></p> <p>Changes to the grid parameters are now blocked. In order to be able to make changes to the grid parameters, from now on you must log in using the SMA Grid Guard code.</p>
9005	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Waiting for host computer</b></p> <p>This error can have the following causes:</p> <ul style="list-style-type: none"><li>• The parameters to be changed are protected.</li><li>• The DC voltage at the DC input is not sufficient to run the main CPU.</li></ul> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Enter the SMA Grid Guard code.</li><li>• Ensure that at least the DC start voltage is available (green LED is flashing, pulsing or glowing).</li></ul>

Event number	Message, cause and corrective measures
9007	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Abort self-test</b></p> <p>The self-test (Italy only) was terminated.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Ensure that the AC connection is correct.</li> </ul>
9301	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>New battery detected</b></p> <p>The inverter has detected a new battery.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Ensure that the correct battery type has been configured when replacing the battery.</li> <li>• If this message occurs even though the battery was not replaced, contact Service (see Section 16 "Contact", page 100).</li> </ul>
9303	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>The service life of the battery is expiring</b></p> <p>The minimum service life defined by the battery manufacturer has been reached.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Contact the battery manufacturer and discuss what to do next.</li> </ul>
9304	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Fault in battery connection &gt; Check battery connection</b></p> <p>This message can have several causes:</p> <ul style="list-style-type: none"> <li>• The battery power cable is either not connected to the battery or not properly connected to the inverter.</li> <li>• The CAN communication between battery and inverter is disturbed.</li> <li>• The lid of the connection box at the battery is not closed properly.</li> <li>• The battery is faulty.</li> </ul> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Make sure that the battery communication cable and the battery power cable are properly connected to the inverter as well as to the battery.</li> <li>• Ensure the perfect operation of the battery.</li> <li>• If the battery communication cable and the battery power cable have been properly connected and the correct operation of the battery is ensured, contact Service (see Section 16 "Contact", page 100).</li> </ul>

Event number	Message, cause and corrective measures
9305	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Unauthorized battery system</b></p> <p>The inverter has detected an incorrect battery.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Only operate batteries with the inverter approved by SMA Solar Technology AG.</li></ul>
9306	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Deviation in battery voltage</b></p> <p>Too high a deviation between the battery and DC voltage of inverter was detected.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Make sure that the battery power cable is correctly connected.</li><li>• If this error is repeated frequently, contact the Service (see Section 16 "Contact", page 100).</li></ul>
9307	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Battery system defective (ID [xx])</b></p> <p>The battery has detected an internal error.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Note the displayed error ID and look for that ID in the battery manufacturer's error list.</li><li>• Carry out the corrective measures indicated in the battery manufacturer's error list.</li><li>• Contact the Service (see Section 16 "Contact", page 100).</li></ul>
9308	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Communication fault in battery system &gt; Check battery connection</b></p> <p>The inverter receives invalid data or no data from the battery.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Make sure that the battery communication cable is properly connected to the inverter as well as to the battery.</li><li>• Ensure that the battery has been approved for operation with the inverter.</li><li>• Ensure the perfect operation of the battery.</li><li>• If the battery communication cable has been properly connected and the correct operation of the battery is ensured, contact Service (see Section 16 "Contact", page 100).</li></ul>

Event number	Message, cause and corrective measures
9311	<div data-bbox="311 180 583 217"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 233 589 261"><b>Battery cell overvoltage fault</b></p> <p data-bbox="292 268 908 296">The battery has detected an overvoltage of at least one battery cell.</p> <p data-bbox="292 303 508 328"><b>Corrective measures:</b></p> <ul data-bbox="311 335 949 427" style="list-style-type: none"> <li data-bbox="311 335 949 392">• If a service contract with SMA Solar Technology AG exists, contact Service (see Section 16 "Contact", page 100).</li> <li data-bbox="311 397 788 427">• If no service contract exists, contact your supplier.</li> </ul>
9312	<div data-bbox="311 440 583 477"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 493 602 521"><b>Battery cell undervoltage fault</b></p> <p data-bbox="292 528 919 557">The battery has detected an undervoltage of at least one battery cell.</p> <p data-bbox="292 563 508 588"><b>Corrective measures:</b></p> <ul data-bbox="311 595 949 687" style="list-style-type: none"> <li data-bbox="311 595 949 652">• If a service contract with SMA Solar Technology AG exists, contact Service (see Section 16 "Contact", page 100).</li> <li data-bbox="311 657 788 687">• If no service contract exists, contact your supplier.</li> </ul>
9313	<div data-bbox="311 700 583 737"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 753 866 782"><b>Low temperature fault in battery &gt; Check installation site</b></p> <p data-bbox="292 788 975 845">The lower limit of the temperature range approved by the battery manufacturer has been exceeded.</p> <p data-bbox="292 852 508 877"><b>Corrective measures:</b></p> <ul data-bbox="311 884 975 948" style="list-style-type: none"> <li data-bbox="311 884 975 948">• Make sure that the ambient conditions of the battery manufacturer are complied with.</li> </ul>
9314	<div data-bbox="311 960 583 997"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 1013 871 1042"><b>Overtemperature fault in battery &gt; Check installation site</b></p> <p data-bbox="292 1048 975 1106">The upper limit of the temperature range approved by the battery manufacturer has been exceeded.</p> <p data-bbox="292 1112 508 1137"><b>Corrective measures:</b></p> <ul data-bbox="311 1144 975 1208" style="list-style-type: none"> <li data-bbox="311 1144 975 1208">• Make sure that the ambient conditions of the battery manufacturer are complied with.</li> </ul>
9315	<div data-bbox="311 1220 583 1257"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 1273 552 1302"><b>Battery imbalancing fault</b></p> <p data-bbox="292 1308 889 1337">The states of charge of the individual battery cells differ too much.</p> <p data-bbox="292 1343 508 1369"><b>Corrective measures:</b></p> <ul data-bbox="311 1375 949 1460" style="list-style-type: none"> <li data-bbox="311 1375 949 1433">• If a service contract with SMA Solar Technology AG exists, contact Service (see Section 16 "Contact", page 100).</li> <li data-bbox="311 1437 788 1460">• If no service contract exists, contact your supplier.</li> </ul>



Event number	Message, cause and corrective measures
9334	<b>Battery charging test</b> The battery test for charging the battery was started.
9335	<b>Discharge battery test</b> The battery test for discharging the battery was started.
9336	<div><b>⚠ QUALIFIED PERSON</b></div> <b>Start conditions for battery test not fulfilled</b> The battery test cannot be started since the start conditions for the battery test are not fulfilled. <b>Corrective measures:</b> <ul style="list-style-type: none"> <li>• Ensure that the battery is not charged above 98% and that the battery state of charge is not 2% above the lower discharge threshold.</li> <li>• Ensure the perfect operation of the battery.</li> <li>• Make sure that the grid connection conditions are met.</li> </ul>
9337	<b>Charge battery test successful</b> The battery test for charging the battery was carried out successfully.
9338	<b>Battery discharging test successful</b> The battery test for discharging the battery was carried out successfully.
9339	<div><b>⚠ QUALIFIED PERSON</b></div> <b>Battery charging test failed</b> The battery test for charging the battery was not carried out successfully. The power required in the test was not reached. The battery or the inverter limited the power due to normative requirements. <b>Corrective measures:</b> <ul style="list-style-type: none"> <li>• Carry out the test again at a later time.                If a power limitation occurred due to normative requirements, check whether the battery is charging after commissioning.</li> </ul>
9340	<div><b>⚠ QUALIFIED PERSON</b></div> <b>Battery discharging test failed</b> The battery test for discharging the battery was not carried out successfully. <b>Corrective measures:</b> <ul style="list-style-type: none"> <li>• Make sure that the battery has been approved for operation with the inverter.</li> <li>• Carry out the test again at a later time.</li> <li>• Make sure that the inverter and the battery are not currently in a power reduction state.</li> </ul>

Event number	Message, cause and corrective measures
9345	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Battery charging for start process too low</b></p> <p>The state of charge of the battery is too low for the start process. The inverter can no longer charge the battery by itself. The battery must be charged by a qualified person. This message causes a permanent operation inhibition, which must be reset manually.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• If a service contract with SMA Solar Technology AG exists, contact Service (see Section 16 "Contact", page 100) and instruct them to manually charge the battery.</li> <li>• If no service contract exists, contact your supplier.</li> </ul>
10100	<p><b>Parameter [xx] set successfully. [xx] to [xx]</b></p> <p>The displayed parameter was successfully changed.</p>
10101	<p><b>Setting of parameter [xx] failed. [xx] to [xx]</b></p> <p>The displayed parameter was not changed.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Make sure thresholds of the parameters are complied with.</li> <li>• Change the parameter again.</li> </ul>
10102	<p><b>Parameter [xx] set successfully. [xx] to [xx]</b></p> <p>The displayed parameter was successfully changed.</p>
10103	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>Setting of parameter [xx] failed. [xx] to [xx]</b></p> <p>The displayed parameter was not changed.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Make sure thresholds of the parameters are complied with.</li> <li>• Change the parameter again.</li> </ul>
10110	<p><b>Time synchronization failed: [x]</b></p> <p>No time information could be called up from the set NTP server.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Ensure that the NTP server was configured correctly.</li> <li>• Ensure that the inverter is integrated into a local network with Internet connection.</li> </ul>
10118	<p><b>Parameter upload complete</b></p> <p>The configuration file was loaded successfully.</p>

Event number	Message, cause and corrective measures
10248 to 10249	<p><b>Load reduced through device reduction or increase of query interval</b></p> <p>The network is busy. Data exchange between the devices is not at an optimum and is greatly delayed.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Reduce the number of devices in the network.</li><li>• If necessary, increase the data query intervals.</li><li>• If necessary, reduce the number of devices in the network.</li></ul>
10250	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>[Interface]: package error rate [ok / high]</b></p> <p>The package error rate has changed. If the package error rate is high, the network is overloaded or the connection to the network switch or DHCP server (router) is disturbed.</p> <p><b>Corrective measures if the package error rate is high:</b></p> <ul style="list-style-type: none"><li>• Ensure that with an Ethernet connection, the network cable and the network connector are not damaged and that the network connectors are correctly plugged.</li><li>• If necessary, increase the data query intervals.</li><li>• If necessary, reduce the number of devices in the network.</li></ul>
10251	<p><b>[Interface]: communication status goes to [OK / Warning / Error / Not connected]</b></p> <p>The communication status to the network switch or DHCP server (router) has changed. An additional error message may be displayed.</p>
10252	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>[Interface]: communication disrupted</b></p> <p>There is no valid signal on the network line.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Ensure that with an Ethernet connection, the network cable and the network connector are not damaged and that the network connectors are correctly plugged.</li><li>• Ensure that the DHCP server (router) and any network switches are signalizing correct operation.</li></ul>

Event number	Message, cause and corrective measures
10253	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>[Interface]: connection speed goes to [100 Mbit / 10 Mbit]</b></p> <p>The data transfer rate has changed. The cause for the status [10 Mbit] can be a defective plug, a defective cable or the pulling or plugging of the network connector.</p> <p><b>Corrective measures if the status is [10 Mbit]:</b></p> <ul style="list-style-type: none"> <li>• Ensure that with an Ethernet connection, the network cable and the network connector are not damaged and that the network connectors are correctly plugged.</li> <li>• Ensure that the DHCP server (router) and any network switches are signalizing correct operation.</li> </ul>
10254	<p><b>⚠ QUALIFIED PERSON</b></p> <p><b>[Interface]: duplex mode goes to [Full / Half]</b></p> <p>The duplex mode (data transfer mode) has changed. The cause for the status [Half] can be a defective plug, a defective cable or the pulling or plugging of the network connector.</p> <p><b>Corrective measures if the status is [Half]:</b></p> <ul style="list-style-type: none"> <li>• Ensure that with an Ethernet connection, the network cable and the network connector are not damaged and that the network connectors are correctly plugged.</li> <li>• Ensure that the DHCP server (router) and any network switches are signalizing correct operation.</li> </ul>
10255	<p><b>[Interface]: Network load OK</b></p> <p>The network load has returned to a normal range after being busy.</p>
10282	<p><b>[User group]-Login via [protocol] locked</b></p> <p>After several incorrect login attempts, login has been blocked for a limited time. In this case, the User login will be blocked for 15 minutes, the Grid Guard login for 12 hours.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Wait until the given time has expired and then retry login.</li> </ul>
10283	<p><b>WLAN module faulty</b></p> <p>The WLAN module integrated in the inverter is defective.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Contact the Service (see Section 16 "Contact", page 100).</li> </ul>

Event number	Message, cause and corrective measures
10284	<div data-bbox="292 180 596 220"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 236 605 260"><b>No WLAN connection possible</b></p> <p data-bbox="292 272 986 323">The inverter does not currently have a WLAN connection to the selected network.</p> <p data-bbox="292 336 507 360"><b>Corrective measures:</b></p> <ul data-bbox="311 368 997 579" style="list-style-type: none"> <li>• Ensure that the SSID, the WLAN password and the encryption method have been entered correctly. The encryption method is specified by your WLAN router or WLAN Access Point and can be changed there.</li> <li>• Ensure that the WLAN router or WLAN Access Point is in range and is signaling correct operation.</li> <li>• If this message is displayed often, improve the WLAN connection by using a WLAN repeater.</li> </ul>
10285	<p data-bbox="292 592 600 616"><b>WLAN connection established</b></p> <p data-bbox="292 628 885 652">Connection to the selected WLAN network has been established.</p>
10286	<div data-bbox="292 668 596 708"><b>⚠ QUALIFIED PERSON</b></div> <p data-bbox="292 721 519 745"><b>WLAN connection lost</b></p> <p data-bbox="292 758 869 782">The inverter has lost WLAN connection to the selected network.</p> <p data-bbox="292 794 507 818"><b>Corrective measures:</b></p> <ul data-bbox="311 826 977 979" style="list-style-type: none"> <li>• Ensure that the WLAN router or WLAN Access Point is still active.</li> <li>• Ensure that the WLAN router or WLAN Access Point is in range and is signaling correct operation.</li> <li>• If this message is displayed often, improve the WLAN connection by using a WLAN repeater.</li> </ul>
10339	<p data-bbox="292 992 510 1016"><b>Webconnect enabled</b></p> <p data-bbox="292 1029 981 1088">The inverter can communicate with Sunny Portal without an additional SMA communications product (e.g. Sunny Home Manager).</p>
10340	<p data-bbox="292 1101 514 1125"><b>Webconnect disabled</b></p> <p data-bbox="292 1137 997 1217">The Webconnect function has been switched off. This means that the inverter can not communicate with Sunny Portal without an additional SMA communications product (e.g. Sunny Home Manager).</p> <ul data-bbox="311 1225 988 1281" style="list-style-type: none"> <li>• If the inverter is to communicate with Sunny Portal without an additional SMA communication product, switch the Webconnect function on.</li> </ul>

Event number	Message, cause and corrective measures
10341	<p><b>Webconnect error: no connection</b></p> <p>It is likely that there is an error in the network settings.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Check the network components (DLAN, WLAN Access Point etc.).</li> <li>• Ensure that the following ports are not blocked:               <ul style="list-style-type: none"> <li>- Registrar: ied.sma.de:9523</li> <li>- Proxy: ied.sma.de:9523</li> <li>- Stun: stun.sma.de:3478</li> <li>- Domain: ied.sma.de (for SIP URI)</li> </ul> </li> </ul>
10343	<p><b>Webconnect error: Default gateway not configured</b></p> <p>It is likely that there is an error in the network settings.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Check the network components (DLAN, WLAN Access Point etc.).</li> <li>• Ensure that the following ports are not blocked:               <ul style="list-style-type: none"> <li>- Registrar: ied.sma.de:9523</li> <li>- Proxy: ied.sma.de:9523</li> <li>- Stun: stun.sma.de:3478</li> <li>- Domain: ied.sma.de (for SIP URI)</li> </ul> </li> </ul>
10344	<p><b>Webconnect error: DNS server not configured</b></p> <p>It is likely that there is an error in the network settings.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Check the network components (DLAN, WLAN Access Point etc.).</li> <li>• Ensure that the following ports are not blocked:               <ul style="list-style-type: none"> <li>- Registrar: ied.sma.de:9523</li> <li>- Proxy: ied.sma.de:9523</li> <li>- Stun: stun.sma.de:3478</li> <li>- Domain: ied.sma.de (for SIP URI)</li> </ul> </li> </ul>
10345	<p><b>No reply to DNS request</b></p> <p>It is likely that there is an error in the network settings.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• Check the network components (DLAN, WLAN Access Point etc.).</li> <li>• Ensure that the following ports are not blocked:               <ul style="list-style-type: none"> <li>- Registrar: ied.sma.de:9523</li> <li>- Proxy: ied.sma.de:9523</li> <li>- Stun: stun.sma.de:3478</li> <li>- Domain: ied.sma.de (for SIP URI)</li> </ul> </li> </ul>

Event number	Message, cause and corrective measures
10346	<p><b>SIP proxy DNS resolution failed</b></p> <p>It is likely that there is an error in the network settings.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Check the network components (DLAN, WLAN Access Point etc.).</li><li>• Ensure that the following ports are not blocked:<ul style="list-style-type: none"><li>- Registrar: ied.sma.de:9523</li><li>- Proxy: ied.sma.de:9523</li><li>- Stun: stun.sma.de:3478</li><li>- Domain: ied.sma.de (for SIP URI)</li></ul></li></ul>
10347	<p><b>Stun server DNS resolution failed</b></p> <p>It is likely that there is an error in the network settings.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Check the network components (DLAN, WLAN Access Point etc.).</li><li>• Ensure that the following ports are not blocked:<ul style="list-style-type: none"><li>- Registrar: ied.sma.de:9523</li><li>- Proxy: ied.sma.de:9523</li><li>- Stun: stun.sma.de:3478</li><li>- Domain: ied.sma.de (for SIP URI)</li></ul></li></ul>
10348	<p><b>Webconnect error: No reply to request to STUN server</b></p> <p>It is likely that there is an error in the network settings.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"><li>• Check the network components (DLAN, WLAN Access Point etc.).</li><li>• Ensure that the following ports are not blocked:<ul style="list-style-type: none"><li>- Registrar: ied.sma.de:9523</li><li>- Proxy: ied.sma.de:9523</li><li>- Stun: stun.sma.de:3478</li><li>- Domain: ied.sma.de (for SIP URI)</li></ul></li></ul>

Event number	Message, cause and corrective measures
10349	<p data-bbox="292 185 785 209"><b>Webconnect error: No reply to SIP option packs</b></p> <p data-bbox="292 220 1005 272">It is likely that there is an error in the network settings or a Sunny Portal maintenance message is present.</p> <p data-bbox="292 284 507 308"><b>Corrective measures:</b></p> <ul data-bbox="311 319 936 576" style="list-style-type: none"> <li>• If a Sunny Portal maintenance message is present, wait until the maintenance has been completed.</li> <li>• Check the network components (DLAN, WLAN Access Point etc.).</li> <li>• Ensure that the following ports are not blocked:               <ul data-bbox="356 451 684 576" style="list-style-type: none"> <li>– Registrar: ied.sma.de:9523</li> <li>– Proxy: ied.sma.de:9523</li> <li>– Stun: stun.sma.de:3478</li> <li>– Domain: ied.sma.de (for SIP URI)</li> </ul> </li> </ul>
10350	<p data-bbox="292 592 863 616"><b>Webconnect error: Registration rejected by SIP registrar</b></p> <p data-bbox="292 627 776 651">It is likely that there is an error in the network settings.</p> <p data-bbox="292 662 507 686"><b>Corrective measures:</b></p> <ul data-bbox="311 697 936 890" style="list-style-type: none"> <li>• Check the network components (DLAN, WLAN Access Point etc.).</li> <li>• Ensure that the following ports are not blocked:               <ul data-bbox="356 764 684 890" style="list-style-type: none"> <li>– Registrar: ied.sma.de:9523</li> <li>– Proxy: ied.sma.de:9523</li> <li>– Stun: stun.sma.de:3478</li> <li>– Domain: ied.sma.de (for SIP URI)</li> </ul> </li> </ul>
10351	<p data-bbox="292 906 514 930"><b>Unknown SIP registry</b></p> <p data-bbox="292 941 776 965">It is likely that there is an error in the network settings.</p> <p data-bbox="292 976 507 1000"><b>Corrective measures:</b></p> <ul data-bbox="311 1011 936 1204" style="list-style-type: none"> <li>• Check the network components (DLAN, WLAN Access Point etc.).</li> <li>• Ensure that the following ports are not blocked:               <ul data-bbox="356 1078 684 1204" style="list-style-type: none"> <li>– Registrar: ied.sma.de:9523</li> <li>– Proxy: ied.sma.de:9523</li> <li>– Stun: stun.sma.de:3478</li> <li>– Domain: ied.sma.de (for SIP URI)</li> </ul> </li> </ul>



Event number	Message, cause and corrective measures
10352	<p><b>Webconnect error: Faulty communication</b></p> <p>It is likely that there is an error in the network settings or a Sunny Portal maintenance message is present.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• If a Sunny Portal maintenance message is present, wait until the maintenance has been completed.</li> <li>• Check the network components (DLAN, WLAN Access Point etc.).</li> <li>• Ensure that the following ports are not blocked: <ul style="list-style-type: none"> <li>– Registrar: ied.sma.de:9523</li> <li>– Proxy: ied.sma.de:9523</li> <li>– Stun: stun.sma.de:3478</li> <li>– Domain: ied.sma.de (for SIP URI)</li> </ul> </li> </ul>
10353	<p><b>Webconnect error: registration of the SIP registry has not responded</b></p> <p>It is likely that there is an error in the network settings or a Sunny Portal maintenance message is present.</p> <p><b>Corrective measures:</b></p> <ul style="list-style-type: none"> <li>• If a Sunny Portal maintenance message is present, wait until the maintenance has been completed.</li> <li>• Check the network components (DLAN, WLAN Access Point etc.).</li> <li>• Ensure that the following ports are not blocked: <ul style="list-style-type: none"> <li>– Registrar: ied.sma.de:9523</li> <li>– Proxy: ied.sma.de:9523</li> <li>– Stun: stun.sma.de:3478</li> <li>– Domain: ied.sma.de (for SIP URI)</li> </ul> </li> </ul>
10420	<p><b>Internal consumption control was started</b></p> <p>The battery is automatically charged or discharged depending on the purchased electricity or the grid feed-in.</p>
10421	<p><b>Internal consumption control was stopped</b></p> <p>The automatic charging or discharging of the battery stopped due to an external control command.</p>
10422	<p><b>Only charging operation in internal consumption mode</b></p> <p>The battery is charged only when increased self-consumption is active. The battery is only charged again once there is sufficient PV power in the system.</p>
10425	<p><b>The device switches off</b></p> <p>The battery is switched off in order to protect against deep discharge. The inverter can only be recommissioned once it has been disconnected from the utility grid.</p>

Event number	Message, cause and corrective measures
10517	<b>Dynamic active power limitation started.</b> The inverter limits the active power of the PV inverters to the set limit.
10518	<b>Dynamic active power limitation terminated.</b> The inverter terminated the active power limitation of the PV inverters.
10520	<div><b>⚠ QUALIFIED PERSON</b></div> <b>Supplied power: [xx] W (permitted value: [xx] W)</b> The set active power limitation cannot be met. <b>Corrective measures:</b> <ul style="list-style-type: none"> <li>• Ensure that the correct active power limitation has been configured.</li> <li>• Ensure that the communication between battery inverter and PV inverter functions perfectly.</li> <li>• Ensure that no external feeders are in the system.</li> </ul>
10521	<b>Active power was limited today for [xx] minutes.</b> The active power limitation of the PV inverters was limited for the specified time.
27103	<b>Set parameter</b> The parameter change has been adopted.
27104	<b>Parameters set successfully</b> The parameter changes were successfully adopted.
27107	<b>Update file OK</b> The update file is suitable for this inverter and its components and is fully available for the next update step.
27301	<b>Update communication</b> The inverter is updating the communication component.
27302	<b>Update main CPU</b> The inverter is updating the inverter component.
27312	<b>Update completed</b> The inverter has successfully completed the update.
27336	<b>Battery management system</b> The inverter is updating the battery.

Event number	Message, cause and corrective measures
29001	<b>Inst. code valid</b> The entered Grid Guard code is valid. Protected parameters have now been unlocked and you can adjust the parameters. The parameters will be automatically locked again after ten feed-in hours.
29004	<b>Grid parameters unchanged</b> Changing the grid parameters is not possible.

## 12.3 Updating the Firmware

### QUALIFIED PERSON

If no automatic update for the inverter is enabled in the communication product (e.g. Sunny Home Manager) or in Sunny Portal, you can update the inverter firmware and thus the battery firmware as follows.

#### **Faulty firmware update due to disconnecting the inverter from the utility grid.**

The inverter must be connected to the utility grid during the firmware update. This will ensure a proper firmware update.

- Do not disconnect the inverter from the utility grid during the firmware update.

#### **Requirements:**

- ☐ An update file with the desired inverter firmware must be available. The update file is, for example, available for download on the product page of the inverter at [www.SMA-Solar.com](http://www.SMA-Solar.com).

#### **Procedure:**

1. Activate the user interface (see Section 8.1, page 46).
2. Log into the user interface (see Section 8.2, page 49).
3. Select the menu **System Configuration**.
4. Select **[Settings]**.
5. In the subsequent context menu, select **[Updating the firmware]**.
6. Follow the instructions in the dialog.

# 13 Decommissioning the Inverter

## ⚠ QUALIFIED PERSON

### ⚠ CAUTION

#### Risk of injury when lifting the inverter, or if it is dropped

The inverter weighs 9 kg. There is risk of injury if the inverter is lifted incorrectly or dropped while being transported or when attaching it to or removing it from the wall mounting bracket.

- Transport and lift the inverter carefully.

#### Procedure:

#### 1. ⚠ DANGER

##### Danger to life due to high voltages


- Disconnect the inverter from all voltage sources (see Section 10, page 63).

#### 2. ⚠ CAUTION

##### Risk of burns due to hot enclosure parts


- Wait 30 minutes for the enclosure to cool down.

3. Remove the conductors from the connecting terminal plate for the connection of the battery communication cable.




4. Remove the conductors from the DC connectors (see Section 6.3.3, page 33).


5. Remove the L, N and grounding conductor from the connecting terminal plate for the AC connection. To do this, stick a flat-blade screwdriver (blade width: 3 mm) as far as it can go into the rectangular opening behind the terminal and remove the conductors from the terminals.




6. Tighten the connection cap to the inverter using the three screws and a Torx screwdriver (TX20) (torque: 3.5 Nm).




7. Screw the swivel nuts onto the cable glands on the connection cap.




8. If an additional grounding or an equipotential bonding is connected to the inverter, remove the cap screw using a Torx screwdriver (TX 25) and remove the grounding cable.



9. Using a ratchet or a box wrench, slightly loosen the screws for attaching the inverter.



10. Remove the inverter from the screws using the metal brackets.



11. If the inverter is to be stored or shipped, pack the inverter. Use the original packaging or packaging that is suitable for the weight and dimensions of the inverter.
12. Dispose of the inverter in accordance with the locally applicable disposal regulations for electronic waste.

## 14 Spare Parts

You will find the spare parts for your product in the following overview. If required, these can be ordered from SMA Solar Technology AG or your distributor.

Designation	Brief description	SMA order number
Enclosure lid	Enclosure lid white	101840-00.01
Connection cap	Connection cap for covering the connection area	102143-00.01
accessory kit	Accessory kit with DC connectors, grounding terminal for additional grounding, connecting terminal plate for the AC connection and connecting terminal plate for the connection of the battery communication cable	101439-00.01

# 15 Technical Data

## AC Connection

Rated power at 230 V, 50 Hz	2500 W
Maximum apparent AC power at $\cos \varphi = 1$	2500 VA
Rated grid voltage	230 V
Nominal AC voltage	220 V / 230 V / 240 V
AC voltage range*	180 V to 280 V
Nominal AC current at 220 V	11 A
Nominal AC current at 230 V	11 A
Nominal AC current at 240 V	10.5 A
Maximum AC current	11 A
Total harmonic distortion of the AC current at total harmonic distortion of the AC voltage < 2%, and the AC power > 50% of the rated power	≤3 %
Maximum output current under fault conditions	19 A
Inrush current	< 20% of the nominal AC current for a maximum of 10 ms
Rated power frequency	50 Hz
AC power frequency*	50 Hz / 60 Hz
Operating range at AC power frequency 50 Hz	45 Hz to 55 Hz
Operating range at AC power frequency 60 Hz	55 Hz to 65 Hz
Power factor at rated power	1
Displacement power factor $\cos \varphi$ , adjustable	0.8 overexcited to 1 to 0.8 underexcited
Feed-in phases	1
Phase connection	1
Overvoltage category in accordance with IEC 60664-1	III

\* depending on the configured country data set

## Battery DC Input

Maximum DC power at $\cos \varphi = 1$	2650 W
Maximum DC Voltage	500 V
Voltage range	100 V to 500 V
DC rated voltage	360 V



Minimum DC voltage	100 V
DC start voltage	100 V
Maximum DC current	10 A
Maximum short-circuit current	18 A
Battery type*	Li-ion
Overvoltage category in accordance with IEC 60664-1	III

\* Only use batteries approved by SMA Solar Technology AG (see list of approved batteries at [www.SMA-Solar.com](http://www.SMA-Solar.com))

## Protective Devices

DC reverse polarity protection	Not available
Input-side disconnection point	Not available
AC short-circuit current capability	Current control
Ground fault monitoring	Available
Grid monitoring	SMA Grid Guard 6
Maximum permissible fuse protection	16 A
All-pole sensitive residual-current monitoring unit	Available

## General Data

Width x height x depth with connection cap	450 mm x 357 mm x 122 mm
Weight	9.2 kg
Length x width x height of the packaging	597 mm x 399 mm x 238 mm
Weight including packaging	11.5 kg
Climatic category in accordance with IEC 60721-3-4	4K4H
Environmental category	Outdoors
Pollution degree outside the inverter	3
Pollution degree inside the inverter	2
Operating temperature range	-40 °C to +60 °C
Maximum permissible value for relative humidity, non-condensing	100 %
Maximum operating altitude above mean sea level	3000 m
Noise emission, typical	< 25 dB

Self-consumption in standby operation	< 2 W
Self-consumption without the load necessary to supply the battery	< 10 W
Maximum data volume per inverter with Speed-wire/Webconnect	550 MB/month
Additional data volume when using the Sunny Portal live interface	600 kB/hour
WLAN range in free-field conditions	100 m
Quantity maximum detectable WLAN networks	32
Topology	Transformerless
Cooling method	Convection
Degree of protection in accordance with IEC 60529	IP65
Protection class in accordance with IEC 62103	I
Grid configurations	TN-C, TN-S, TN-CS, TT (if $V_{N,PE} < 30$ V), IT, Delta IT, split phase
National standards and approvals, as per 02/2016*	AS 4777.2:2015, C10/11/2012, CEI 0-21, EN 50438:2013, G83/2, IEC 61727, IEC 62109-2, NEN-EN50438, NRS097, PPC, PPDS, RD 1699, VDE-AR-N 4105, VDE 0126-1-1, VFR2014

\* **IEC 62109-2:** In order to meet the requirements of this standard, there must be a link to Sunny Portal with the fault alert via e-mail activated.

## Climatic Conditions

### Installation in accordance with IEC 60721-3-4, Class 4K4H

Extended temperature range	-40 °C to +60 °C
Extended humidity range	0% to 100%
Extended air pressure range	79.5 kPa to 106 kPa

### Transport in accordance with IEC 60721-3-4, Class 2K3

Extended temperature range	-25 °C to +70 °C
----------------------------	------------------

## Equipment

DC connection	DC connector
AC connection	Spring-cage terminal
Battery communication	CAN bus

Speedwire interface	As standard
Webconnect function	As standard
WLAN interface	As standard

## Torques

Screws for mounting	Hand-tight
Swivel nut of the DC connector	2 Nm
Swivel nut of the cable gland for the AC connection.	Hand-tight
Swivel nut cable gland network and battery communication connection	Hand-tight
Screws for attaching the connection cap	3.5 Nm $\pm$ 0.3 Nm
Screw for additional grounding	6 Nm $\pm$ 0.3 Nm
Screws for attaching the enclosure lid	6 Nm $\pm$ 0.3 Nm

## Data Storage Capacity

Energy yields in the course of the day	63 days
Daily yields	30 years
Event messages for users	1000 events
Event messages for installers	1000 events

## Efficiency

Maximum efficiency, $\eta_{\max}$	97.0 %
European weighted efficiency, $\eta_{\text{EU}}$	96.5 %

## 16 Contact

If you have technical problems with our products, please contact the SMA Service Line. We require the following information in order to provide you with the necessary assistance:

- Inverter device type
- Inverter serial number
- Inverter firmware version
- Special country-specific settings of the inverter (if applicable)
- Mounting location and altitude of the inverter
- Inverter message
- Optional equipment, e.g. communication products
- Type of battery connected
- Firmware version of the battery

Danmark	SMA Solar Technology AG	Belgien	SMA Benelux BVBA/SPRL
Deutschland	Niestetal	Belgique	Mechelen
Österreich	SMA Online Service Center:	België	+32 15 286 730
Schweiz	www.SMA-Service.com	Luxemburg	
	Sunny Boy, Sunny Mini Central, Sunny Tripower:	Luxembourg	
	+49 561 9522-1499	Nederland	
	Monitoring Systems (Kommunikationsprodukte):	Česko	SMA Service Partner TERMS a.s.
	+49 561 9522-2499	Magyarország	+420 387 6 85 111
	Fuel Save Controller (PV-Diesel-Hybridssysteme):	Slovensko	
	+49 561 9522-3199		
	Sunny Island, Sunny Boy Storage, Sunny Backup, Hydro Boy:	Polska	SMA Polska
	+49 561 9522-399		+48 12 283 06 66
	Sunny Central:		
	+49 561 9522-299		
France	SMA France S.A.S.	Ελλάδα	SMA Hellas AE
	Lyon	Κύπρος	Αθήνα
	+33 472 22 97 00		+30 210 9856666
España	SMA Ibérica Tecnología Solar, S.L.U.	United Kingdom	SMA Solar UK Ltd.
Portugal	Barcelona		Milton Keynes
	+34 935 63 50 99		+44 1908 304899

Bulgaria	SMA Italia S.r.l.	France	SMA France S.A.S.
Italy	Milano		Lyon
România	+39 02 8934-7299		+33 472 22 97 00
United Arab Emirates	SMA Middle East LLC Abu Dhabi +971 2234 6177	India	SMA Solar India Pvt. Ltd. Mumbai +91 22 61713888
ไทย	SMA Solar (Thailand) Co., Ltd. กรุงเทพฯ +66 2 670 6999	대한민국	SMA Technology Korea Co., Ltd. 서울 +82-2-520-2666
South Africa	SMA Solar Technology South Africa Pty Ltd. Cape Town 08600SUNNY (08600 78669) International: +27 (0)21 826 0600	Argentina Brasil Chile Perú	SMA South America SPA Santiago +562 2820 2101
Australia	SMA Australia Pty Ltd. Sydney Toll free for Australia: 1800 SMA AUS (1800 762 287) International: +61 2 9491 4200	Other countries	International SMA Service Line Niestetal Toll free worldwide: 00800 SMA SERVICE (+800 762 7378423)

## 17 EU Declaration of Conformity

within the scope of the EU directives

- Electromagnetic compatibility 2014/30/EU (L 96/79-106, March 29, 2014) (EMC)
- Low Voltage Directive 2014/35/EU (L 96/357-374, March 29, 2014) (LVD)
- Radio and telecommunications terminal equipment (R&TTE) 1999/05/EC



SMA Solar Technology AG confirms herewith that the inverters described in this document are in compliance with the fundamental requirements and other relevant provisions of the above-mentioned directives. The entire EU Declaration of Conformity can be found at [www.SMA-Solar.com](http://www.SMA-Solar.com).



ENERGY  
THAT  
CHANGES

